

LTP-X 3.40.0

LTP-8X, LTP-4X

OLT LTP-X

3.40.0 (10.12.2020)

- 1
- 2
 - 2.1
 - 2.2
 - 2.2.1
 - 2.2.2
 - 2.2.3
 - 2.2.4
- 3 [\(CLI\)](#)
 - 3.1 [telnet/ssh](#)
 - 3.2 [serial](#)
 - 3.3
- 4 [LTP-X](#)
- 5 [OLT LTP-X](#)
- 6 [SNMP, SYSLOG, NTP, IP Source GUARD](#)
 - 6.1 [SNMP](#)
 - 6.2 [SYSLOG](#)
 - 6.3 [NTP](#)
 - 6.4 [IP Source Guard](#)
 - 6.5 [DHCP RA \(broadcast — unicast relay\)](#)
- 7 [SWITCH](#)
- 8 [IGMP](#)
- 9 [CROSS_CONNECT, PORTS, ONT](#)
- 10 [OLT - PPPoE Intermedia Agent, DHCP Relay Agent](#)
 - 10.1 [PPPoE Intermedia Agent](#)
 - 10.2 [DHCP Relay Agent](#)
- 11 [ONT](#)
- 12 [ONT](#)
- 13 [LTP ACS](#)
- 14 [ACS ONT](#)
- 15 [ACS](#)
- 16 [ONT ACS](#)
- 17 . [ACS NTP-RG14XXG-W/NTU-RG14XXG-W](#)
- 18 . [NTP-RG14XXG/NTP-RG14XXG-W](#)
- 19 . - [RS-232](#)
- 20 . [ONT NTU-1](#)
- 21 . [ONT SFP-ONU](#)
- 22 . [ONT/GPON-](#)
- 23




, , .



, , .

- OLT LTP-X ();
- OLT;
- VLAN switch;
- IGMP switch;
- ONT: Cross-connect, Ports, Management;
- OLT: pppoe-ia, dhcp-ra;
- ONT.

, 1:



1 —

	VLAN
Internet	2149
VoIP	3149
IPTV (multicast)	30
STB	2349
MNG-ONT (acs)	4094
MNG OLT	4000

, SSH, Telnet, (, HyperTerminal).

« ». ».



1. , .
2. .
3. :
 - -5 +40°C;
 - 80% 25 °C;
 - 6,010*4 10,710*4 (450 800 ..).
4. , , , .
5. .


1. , 0,1 .
2. , . . . 1.
3. .
4. , .
5. :

- LTP-X rev.B ;
 - LTP-X rev.C/rev.D .
6. SFP- , .

12 .


: :

- 1.
- 2.
- 3. 1 2 .



2 —

- : :
- 1.
 - 2.
 - 3. .




3 —




10 .

220, 50 , 48 LTP-X rev.B 4.

LTP-X rev.C/rev.D 5.



4 — LTP-X rev.B



5 — LTP-X rev.C/rev.D

- 1. . ;
- 2. . ;
- 3. .

- 1. . 19"
- 2.
- 3.
- 4.
- 5.

(CLI)

telnet/ssh

«GE Port» «Combo GE» LTP-X. SSH/Telnet :

- Default IP 192.168.1.2
- Default mask 255.255.255.0
- Default GW 0.0.0.0
- Login: admin
- Password: password

```
login:admin  
Password: password
```



IP-, C- (. [serial](#)).

serial

- - . - RS-232.

:

- : 115200 /;
- : 8 ;
- : ;
- : 1;
- : .
- Login: admin
- Password: password



«show management».

```
LTP-X# show management  
Network:  
    Hostname: 'LTP-X'  
    Ipaddr: 192.168.1.2  
    Netmask: 255.255.255.0  
    Vlan management: 1  
    Gateway: 0.0.0.0  
    Vlan prio: 7  
    Dscp: 63
```

```
LTP-X# configure terminal

LTP-X(config)# do show users config

    admin
LTP-X(config)# user admin password XXXX

    root
LTP-X(config)# user root password XXXX

LTP-X(config)# do commit

LTP-X(config)# do save
```

LTP-X

LTP-X , . CLI serial .

```
LTP-X# configure terminal

, , IP=192.168.205.105, Mask=255.255.255.0, Gateway=192.168.205.230, VLAN=4000.
```

```

LTP-X(config)# management ip 192.168.205.105
LTP-X(config)# management mask 255.255.255.0
LTP-X(config)# management gateway 192.168.205.230
LTP-X(config)# management vid 4000
LTP-X(config)# exit

LTP-X# show management
Network:
  Hostname:          'LTP-X'
  Ipaddr:           192.168.205.105
  Netmask:          255.255.255.0
  Vlan management:   4000
  Gateway:          192.168.205.230
  Vlan prio:         7
  Dscp:              63
  Additional vlan:  <list is empty>

/  «commit», «save»  :

LTP-X# commit

LTP-X# save

VLAN (    VID=4000),      SWITCH:
  SWITCH
LTP-X# switch

  SWITCH
LTP-X(config-terminal)#
VLAN
LTP-X(config-terminal)#
  VLAN front- 0
LTP-X(config-vlan)#
  tagged front-port 0
LTP-X(config-vlan)#
LTP-X(config-vlan)# exit

```

```

LTP-X(config-terminal)#
  VLAN
LTP-X(config-terminal)#
  VLAN front- 0
LTP-X(config-vlan)#
  tagged front-port 0
LTP-X(config-vlan)#
LTP-X(config-vlan)# exit

```

```
LTP-X# save
```

OLT LTP-X

```

LTP-X . .
TFTP- ( 3.40.0-build2358).
LTP-X, :

```

```
TFTP-
LTP-8X# copy tftp://192.168.205.250/ltp-8x-revc-revd-3.40.0-build2358.fw.bin
fs://firmware
    Check free memory...ok
    Downloading system firmware...
    .....  
.....  
.....  
System firmware successfully downloaded
Updating system firmware..
    Current board version:      6
    Current firmware version:  3.38.2.16
    New firmware version:     3.40.0.2358
Update device mtd7
    Erase flash...
    Done.
    Write data...
    Done.
    Done.
Success
Update device mtd8
    Erase flash...
    Done.
    Write data...
    Done.
    Done.
Success
Update device mtd5
    Erase flash...
    Done.
    Write data...
    Done.
    Done.
Success
Update device mtd6
    Erase flash...
    Done.
    Write data...
    Done.
    Done.
Success
System firmware successfully updated

LTP-8X#
```

«reboot»:

```
LTP-X# reboot
Do you really want to reboot the system now? (y/n)  y
```

LTP-8X «show version»:

```
LTP-8X# show version
Eltex LTP-8X:rev.C software version 3.40.0 build 2358 on 10.12.2018 15:32
```

SNMP, SYSLOG, NTP, IP Source GUARD

SNMP

SNMP — SNMP .

```

LTP-X# configure terminal

    SNMP
LTP-X(config)# ip snmp enable

    v2    EMS
LTP-X(config)# ip snmp traps 192.168.205.200 type v2

    SNMP
LTP-X(config)# do show ip snmp
  Snmp:
    Enabled:                      true
    Access control:                false
    Allow ip:                     <list is empty>
    Traps [0]:
      Type:                        v2
      Ipaddr:                      192.168.205.200
    Version:
      Community read-only [0]:    'QwYva0dvS3N'
      Community read-only [1]:    'QwYva0dvS3N'
      Community read-only [2]:    'QwYva0dvS3N'
      Community read-write [0]:   'LQtfx9v3m9+qA=='
      Community read-write [1]:   'LQtfx9v3m9+qA=='
      Community read-write [2]:   'LQtfx9v3m9+qA=='
      Trap community:              '9qXUEDwUMAg'
      Location:                    'unknown'
      Contact:                     'admin'
      Alias:                       <for showing use
separate command>
      EngineID:                   0xEF20CAF8234E12401216B17D85
      Users:                      <for showing use separate command>

LTP-X(config)# do commit

LTP-X(config)# do save

```

SYSLOG

Syslog — , .

```

LTP-X# configure terminal

    syslog-
LTP-X(config)# logging remote 192.168.205.200

    SYSLOG
LTP-X(config)# do show logging
    Log:
        Remote syslog:          192.168.205.200
        Port:                  514
        Size:                  16384
        Origin-id:
            Type:                ip
        Save logs between boots: false
        Log input commands:     false
        Destinations:
            System:              notice
            Console:              critical
            Remote shells:        critical
            File:                 notice

LTP-X(config)# do commit

LTP-X(config)# do save

```

NTP

NTP — , .

```

LTP-X# configure terminal

    NTP
LTP-X(config)# ip ntp enable

    NTP-
LTP-X(config)# ip ntp ip 192.168.205.200

    timezone
LTP-X(config)# ip ntp timezone 7

```

```

    NTP
LTP-X(config)# do show ip ntp
    Ntp:
        Enabled:           true
        Ntpserver:         192.168.205.200
        Interval:          3600
        Timezone:          7
        Daylightsaving:   false

LTP-X(config)# do commit

LTP-X(config)# do save

```

IP Source Guard

3.26.0, OLT IP Source Guard, IP- . IP- MAC- ONT.

```

LTP-X# configure terminal

  Source Guard
LTP-X(config)# ip source-guard enable

LTP-X(config)# ip source-guard mode dynamic

```

:

LTP-X(config)# ip source-guard bind ip <IP> mac <MAC> interface-ont <ONT> service <NUM>

:

- *IP*— IP- ...;
- *MAC*— MAC-
- *ONT*— ONT /Y (Channel ID/ONT ID);
- *NUM*— ONT, .

DHCP RA (broadcast — unicast relay)

DHCP- unicast- DHCP Relay Agent. Relay Agent VLAN . c , 802.1q.

1. L3-, IP- VLAN, . DHCP- management-, 3 . DHCP- VLAN, cross-connect, IP- DHCP-, 3 .

```

VLAN
LTP-X(switch)(config)# vlan 2000

IP- VLAN 2000
LTP-X(switch)(config-vlan)# ip address 10.10.10.1/32

```

2. DHCP-.

```

IP- DHCP-
LTP-X(switch)(config-vlan)# ip dhcp relay 192.168.56.1

```

3. L3-, IP- VLAN, , DHCP-.

```

VLAN
LTP-X(switch)(config)# vlan 1209
LTP-X(switch)(config-vlan)# ip address 192.168.209.240/24

```

4. DHCP- , L3-, .

```

LTP-X(config)# ip route prefix 192.168.56.0 mask 24 gateway 192.168.209.5
LTP-X(switch)(config-vlan)# ip address 192.168.209.240/24

```

SWITCH

```

        SWITCH
LTP-X# switch

        SWITCH
LTP-X(switch)# configure

        VLAN
LTP-X(switch)(config)# vlan 2149,2349,30,3149,4094

        pon-
LTP-X(switch)(config-vlan-range)# tagged pon-port 0 - 7

        VLAN front-
LTP-X(switch)(config-vlan-range)# tagged front-port 0

LTP-X(switch)(config-vlan-range)# exit

LTP-X(switch)(config)# commit
LTP-X(switch)(config)# exit
LTP-X(switch)# exit

LTP-X# save

```

*
LTP-8 rev.B HW_revision 2v.
LTP-8 rev./rev.D HW_revision 1v.
LTP-4X rev.B, LTP-4X rev.C «tagged pon-port 0 – 3».

LTP-X :

```

LTP-8X# show system environment
System information:
  CPU load average (1m, 5m, 15m): 0.83 2.35 1.48
  Free RAM/Total RAM (Mbytes): 279/495
  Temperature (sensor1/sensor2): 35C/48C
  Reset button: enabled

  Fan configured speed, %: auto
  Fan minimum speed, %: 15
  Fan speed levels, %: 16 27 39 51 64 76 88 100
  Fan state (fan0/fan1): 6300rpm 6450rpm
  PLD FW version: 14

  TYPE: LTP-8X-rev.C
  HW_revision: 1v1
  SN: GP2B000024
  MAC: A8:F9:4B:8B:50:00

  Power supply information:
  Module 1: PM150 220/12 1vX
    Type: Alternate current(AC)
    Intact: 1
  Module 2: PM150 220/12 1vX
    Type: Alternate current(AC)
    Intact: 1

```



IGMP

```

IGMP SNOOPING
LTP-X(switch)(config)# ip igmp snooping

VLAN
30

LTP-X(switch)(config)# vlan 30

IGMP SNOOPING
VLAN

LTP-X(switch)(config-vlan)# ip igmp snooping enable

IGMP
LTP-X(switch)(config-vlan)# ip igmp snooping querier enable

IGMP-report
LTP-X(switch)(config-vlan)# exit
LTP-X(switch)(config)# ip igmp proxy report enable

IGMP-
    VLAN unicast
multicast

LTP-X(switch)(config)# ip igmp proxy report range 224.0.0.1 239.255.255.255 from 2349 to 30

LTP-X(switch)(config)#
commit

LTP-X(switch)(config)# exit
LTP-X(switch)# exit

LTP-X#
save

```

CROSS_CONNECT, PORTS, ONT

```

LTP-X# configure terminal

datapath
2

LTP-X(config)# gpon olt model 2

Cross-Connect
ONT

LTP-X(config)# profile cross-connect
INTERNET

LTP-X(config-cross-connect)( "INTERNET" )#

VLAN
LTP-X(config-cross-connect)( "INTERNET" )# outer vid 2149

VLAN      ONT
LTP-X(config-cross-connect)( "INTERNET" )# user vid
10
LTP-X(config-cross-connect)( "INTERNET" )# exit

Cross-Connect      SIP VoIP ONT
LTP-X(config)# profile cross-connect VOIP

VLAN

```

VoIP

```
LTP-X(config-cross-connect)( "VOIP")# outer vid 3149
    VLAN  VoIP
ONT
LTP-X(config-cross-connect)( "VOIP")# user vid
12
LTP-X(config-cross-connect)( "VOIP")# exit

    Cross-Connect  multicast
LTP-X(config)# profile cross-connect MC_IPTV

    VLAN
multicast

LTP-X(config-cross-connect)( " MC_IPTV ")# outer vid 30
    VLAN  multicast
ONT
LTP-X(config-cross-connect)( " MC_IPTV ")# user vid 30

    multicast
LTP-X(config-cross-connect)( " MC_IPTV ")# type
multicast
LTP-X(config-cross-connect)( " MC_IPTV ")# exit

    Cross-Connect  UC_IPTV ONT
LTP-X(config)# profile cross-connect UC_IPTV

    VLAN  STB
unicast

LTP-X(config-cross-connect)( " UC_IPTV ")# outer vid 2349
    VLAN  STB unicast
ONT
LTP-X(config-cross-connect)( " UC_IPTV ")# user vid
11
LTP-X(config-cross-connect)( " UC_IPTV ")# exit

    Cross-Connect  management ONT
LTP-X(config)# profile cross-connect ACS

    VLAN
management

LTP-X(config-cross-connect)( "ACS")# outer vid 4094
    VLAN  management
ONT
LTP-X(config-cross-connect)( "ACS")# user vid untagged

    management
LTP-X(config-cross-connect)( "ACS")# type
management
LTP-X(config-cross-connect)( "ACS")# exit

LTP-X(config)# profile ports NTP-RG

IGMP Proxy  VoIP-
NTP

LTP-X(config-ports)( "NTP-RG")# veip multicast

    IGMP-  30-
VLAN

LTP-X(config-ports)( "NTP-RG")# veip upstream vid 30
```

```

      30-
VLAN
LTP-X(config-ports)( " NTP-RG ")# veip downstream vid 30

  VLAN multicast,
LTP-X(config-ports)( " NTP-RG ")# igmp multicast dynamic-entry 0 vid 30

LTP-X(config-ports)( " NTP-RG ")# igmp multicast dynamic-entry 0 group 224.0.0.1 239.255.255.255

LTP-X(config-ports)( " NTP-RG ")# do commit

LTP-X(config-ports)( " NTP-RG ")# do
save

```



, , .

OLT - PPPoE Intermedia Agent, DHCP Relay Agent

PPPoE Intermedia Agent

```

LTP-X# configure terminal

LTP-X(config)# profile pppoe-ia 1

  Agent
LTP-X(config-pppoe-ia)( "1")# enable

  PPPoE-
LTP-X(config-pppoe-ia)( "1")# sessions-limit 8094

  PPPoE-    ONT
LTP-X(config-pppoe-ia)( "1")# sessions-limit per-user 4

  circuit_id
LTP-X(config-pppoe-ia)( "1")# format circuit-id %HOSTNAME%%ONTID%

  remote_id
LTP-X(config-pppoe-ia)( "1")# format remote-id %HOSTNAME%%ONTID%

LTP-X(config-pppoe-ia)( "1")# do commit

LTP-X(config-pppoe-ia)( "1")# do save

  pppoe-ia 1   OLT
LTP-X(config-pppoe-ia)( "1")# exit
LTP-X(config)# gpon olt profile pppoe-ia 1

LTP-X(config)# do commit

LTP-X(config # do
save

```



OLT GPON (Auto reconfigure GPON-port: true), pppoe-ia OLT-.

:

```
LTP-X# reconfigure olt all
```

LTP-4X:

```
LTP-X# reconfigure olt
```

DHCP Relay Agent

```

LTP-X# configure terminal

    DHCP
LTP-X(config)# profile dhcp-ra 1

    Agent
LTP-X(config-dhcp-ra)(1)# enable

    HOSTNAME LTP-X id ONT      ,      DHCP-
LTP-X(config-dhcp-ra)(1)# overwrite-option82 circuit-id %HOSTNAME%%ONTID%

    HOSTNAME LTP-X id ONT      DHCP-
LTP-X(config-dhcp-ra)(1)# overwrite-option82 remote-id %HOSTNAME%%ONTID%

LTP-X(config-dhcp-ra)(1)# do commit

LTP-X(config-dhcp-ra)(1)# do save

LTP-X(config)# gpon olt profile dhcp-ra 1

    1 VLAN 3149
LTP-X(config)# gpon olt profile dhcp-ra 1 vid 3149

LTP-X(config)# do commit

LTP-X(config)# do save

    OLT
LTP-X# show gpon olt configuration
    Block duplicated mac:           enabled
    Disable rogue ONT:             disabled
    Ont block time:                5
    Dhcpра shaper:                 100
    Profile pppoe-ia:              1
    OLT Profile PPPoE Intermediate Agent 1
    Profile dhcp-ra:               1
    OLT Profile DHCP Relay Agent   1
    Profile dhcpcv6-ra:            dhcpcv6-ra-00      OLT Profile DHCP Relay Agent 0
    Profile dhcp-ra per VLAN 3149 [0]:
        Profile:                   1
        OLT Profile DHCP Relay Agent 1
    Profile dhcpcv6-ra per VLAN:    <list is empty>
    Datapath:
        Model:                     model2
        Broadcast gem port:        4095
        Multicast gem port:       4094
    Encryption:
        Enable:                    false
        Key update interval:       1
    Unactivated timeout:            60
    ONT authentication mode:       both
    Auto reconfigure ONT:          true
    Auto reconfigure GPON-port:    true
    Auto reconfigure OLT:          true
    PLOAM password in alarm:     false
    Auto-activation ONT:
        Default template:         unassigned

```

VLAN, 3149, 0 DHCP Relay Agent.
DHCP-RA OLT-, OLT GPON Auto reconfigure GPON-port: true

:

```
LTP-X# reconfigure olt all
```

LTP-4X:

```
LTP-X# reconfigure olt
```

ONT

ONT 454C54580800F6B1 , 0 ONT ID 1 .

```
,      ONT
LTP-X# show interface ont 0-7
unactivated
-----
GPON-port 0 ONT unactivated list
-----
##  Serial          ONT ID   GPON-port Status        RSSI[dBm]  Version    EquipmentID  Description
1  454C54580800F6B1  n/a       0     UNACTIVATED  n/a        n/a        n/a          n/a

LTP-X# configure terminal

 0 ONT ID 1
LTP-X(config)# interface ont 0/1

      ONT
LTP-X(config)(if-ont-0/1)# serial 454C54580800F6B1

  ports NTP-RG
LTP-X(config)(if-ont-0/1)# profile ports NTP-RG

  cross-connect INTERNET
LTP-X(config)(if-ont-0/1)# service 0 profile cross-connect INTERNET

  cross-connect VOIP
LTP-X(config)(if-ont-0/1)# service 1 profile cross-connect VOIP

  cross-connect MC_IPTV
LTP-X(config)(if-ont-0/1)# service 2 profile cross-connect MC_IPTV

  cross-connect UC_IPTV
LTP-X(config)(if-ont-0/1)# service 3 profile cross-connect UC_IPTV

  cross-connect ACS
LTP-X(config)(if-ont-0/1)# service 4 profile cross-connect ACS

  dba «dba 0» :
LTP-X(config)(if-ont-0/1)# service 0 profile dba dba-00
LTP-X(config)(if-ont-0/1)# service 1 profile dba dba-00
LTP-X(config)(if-ont-0/1)# service 2 profile dba dba-00
LTP-X(config)(if-ont-0/1)# service 3 profile dba dba-00
LTP-X(config)(if-ont-0/1)# service 4 profile dba dba-00

LTP-X(config)(if-ont-0/1)# do commit

LTP-X(config)(if-ont-0/1)# do
save
```

10 :

```
LTP-X# send omci restore interface ont 0/1
```

```
ONT,
LTP-X# show interface ont 0-7
online
-----
GPON-port 0 ONT online list
-----
## Serial          ONT ID  GPON-port  Status   RSSI[dBm]    Version     EquipmentID  Description
1  454C54580800F6B1  1        0          OK      -25.38     3.22.0.1493  NTU-RG

Total ONT count: 1
```

ONT

ONT «Template», ONT.

```

LTP-X# configure terminal

TP

LTP-X(config)# template TP

ports

LTP-X(ont-template)(TP)"# profile ports NTP-RG

cross-connect INTERNET service 0 TP
LTP-X(ont-template)(TP)"# service 0 profile cross-connect INTERNET

cross-connect VOIP service 1 TP
LTP-X(ont-template)(TP)"# service 1 profile cross-connect VOIP

cross-connect MC_IPTV service 2 TP
LTP-X(ont-template)(TP)"# service 2 profile cross-connect MC_IPTV

cross-connect STB service 3 TP
LTP-X(ont-template)(TP)"# service 3 profile cross-connect UC_IPTV

cross-connect ACS service 4 TP
LTP-X(ont-template)(TP)"# service 4 profile cross-connect ACS

dba «dba-00» :
LTP-X(ont-template)(TP)"# service 0 profile dba dba-00
LTP-X(ont-template)(TP)"# service 1 profile dba dba-00
LTP-X(ont-template)(TP)"# service 2 profile dba dba-00
LTP-X(ont-template)(TP)"# service 3 profile dba dba-00
LTP-X(ont-template)(TP)"# service 4 profile dba dba-00

LTP-X(ont-template)(TP)"# do commit

LTP-X(ont-template)(TP)"# do
save

ONT 454C54580800F6B2:

LTP-X# configure terminal

0 ONT ID
10

LTP-X(config)# interface ont 0/10

ONT
LTP-X(config)(if-ont-0/10)"# serial 454C54580800F6B2

TP
LTP-X(config)(if-ont-0/10)"# template TP

LTP-X(config)(if-ont-0/10)"# do
commit

```

```
LTP-X(config)(if-ont-0/10)"# do save
```

```
ONT 454C54580800F6B2  ONT 454C54580800F6B1 10,  ONT 2.  ONT [T] .
```

```

LTP-8X(config)(if-ont-0/10)# do show interface ont 0/10 configuration
-----
[ONT0/10] configuration
-----

Description: ''
Enabled: true
Serial: ELTX0800F6B1
Password: '0000000000'
[T] Fec up: false
[T] Downstream broadcast: true
[T] Ber interval: none
[T] Ber update period: 60
[T] Rf port state: disabled
[T] Omci error tolerant: false
    Service [0]:
[T] Profile cross connect: INTERNET     ONT Profile Cross Connect 1
[T] Profile dba: dba-00          ONT Profile DBA 0
        Custom cross connect:
            Service [1]:
[T] Profile cross connect: VOIP         ONT Profile Cross Connect 2
[T] Profile dba: dba-00          ONT Profile DBA 0
        Custom cross connect:
            Service [2]:
[T] Profile cross connect: MC_IPTV      ONT Profile Cross Connect 3
[T] Profile dba: dba-00          ONT Profile DBA 0
        Custom cross connect:
            Service [3]:
[T] Profile cross connect: UC_IPTV      ONT Profile Cross Connect 4
[T] Profile dba: dba-00          ONT Profile DBA 0
        Custom cross connect:
            Service [4]:
[T] Profile cross connect: ACS          ONT Profile Cross Connect 5
[T] Profile dba: dba-00          ONT Profile DBA 0
        Custom cross connect:
            Service [5]:
[T] Profile cross connect: unassigned
[T] Profile dba: dba-00          ONT Profile DBA 0
        Custom cross connect:
[T] Profile shaping: shaping-00      ONT Profile Shaping 0
[T] Profile ports: NTP-RG          ONT Profile Ports 1
[T] Profile management: unassigned
[T] Profile scripting: unassigned
    Custom model:
        Template:
            TP          ONT Template 1
LTP-8X(config)(if-ont-0/10)#

```

LTP ACS

LTP-4/8X rev.B, LTP-4/8X rev.C/rev.D ACS-, ONT, OLT.

```
ACS-
LTP-X(config)# ip acs server enable

VLAN,      ACS-
LTP-X(config)# ip acs server vid 4094

DHCP-    IP ONT
LTP-X(config)# ip dhcp server enable

43  DHCP-
LTP-X(config)# ip dhcp server option-43

LTP-X(config)# ip dhcp server range "192.168.200.2" "192.168.201.254"

LTP-X(config)#do commit
```

```
LTP-X(config)#do save
```

SWITCH

```
LTP-X# switch
```

SWITCH

```
LTP-X(switch)# configure
```

VLAN

ACS

```
LTP-X(switch)(config)# vlan 4094

pon-
LTP-X(switch)(config-vlan)# tagged pon-port 0 -
7
```

```
LTP-X(switch)(config-vlan)# exit
LTP-X(switch)(config)#
commit
LTP-X(switch)(config)# exit
LTP-X(switch)# exit
```

```
LTP-X# save
```

```
LTP-X# configure terminal
```

```
Cross-Connect    management
ONT

LTP-X(config)# profile cross-connect ACS
```

```

VLAN management
LTP-X(config-cross-connect)("ACS")# outer vid
4094
LTP-X(config-cross-connect)("ACS")# type management

LTP-X(config-cross-connect)("ACS")# do commit

LTP-X(config-cross-connect)("ACS")# do save

```

* :
LTP-8 rev.B HW_revision 2v.
LTP-8 rev./rev.D HW_revision 1v.
LTP-4X rev.B/ LTP-4X rev.C «tagged pon-port 0 – 3».

ONT ACS ONT CC Management ONT.

ACS ONT

```

LTP-X> acs

ONT
(acss)# profile

ONT TEST
(acss-profiles)# add profile TEST

TEST
(acss-profiles)# profile TEST
(acss-profile-name='TEST'

(acss-profile-name='TEST')commit
(acss-profile-name='TEST')

```

ACS ONT ftp/tftp.

```
LTP-8x# copy tftp://10.0.0.1/acs-config fs://acs-config
```



OLT . CLI .

```

profile
add profile test1
profile test1
set property InternetGatewayDevice.LANDevice.1.WLANConfiguration.1.PreSharedKey.1.X_ELTEX_RU_UserDefinedPSK
1 nocheck
set property InternetGatewayDevice.LANDevice.1.WLANConfiguration.1.RadioEnabled 1 nocheck

```

ACS

```
(acs)#
(acss) # user
IVANOV
(acss-user) # add user IVANOV
IVANOV
(acss-user) # user IVANOV
ONT
IVANOV
(acss-user-subscriber='IVANOV') # set pon_serial 454C54580800F6B1
ACS    IVANOV
(acss-user-subscriber='IVANOV') # set profile TEST
PPPoE-
(acss-user-subscriber='IVANOV') # set ppp_login test
PPPoE-
(acss-user-subscriber='IVANOV') # set ppp_password TEST
SIP PROXY
(acss-user-subscriber='IVANOV') # set sip_proxy 212.122.111.55
1
(acss-user-subscriber='IVANOV') # set voicel_enable enabled
1
(acss-user-subscriber='IVANOV') # set voicel_number 34234234
1
(acss-user-subscriber='IVANOV') # set voicel_password test
```

ONT ACS



, LTP-X .

```

ACS
LTP-X> acs

ONT

(acs)firmware

TFTP-

(acs-firmware)copy 192.168.16.26 ntp-rg-3.22.1.14.fw.bin

(acs-firmware)show files

(acs-firmware)show list

(acs-firmware)add firmware 1

(acs-firmware)firmware 1

(acs-firmware_config-fw id='1')show config

(acs-firmware_config-fw id='1')set file ntp-rg-3.22.1.14.fw.bin

( ONT,      ).      (acs-profile)  «show list»
(acs-firmware_config-fw id='1')add profile TEST

```

ONT ACS ONT.

« ».

. ACS NTP-RG14XXG-W/NTU-RG14XXG-W

```

set property "InternetGatewayDevice.LANDevice.1.LANHostConfigManagement.DHCPServerEnable" "1" nocheck
set property "InternetGatewayDevice.LANDevice.1.LANHostConfigManagement.DomainName" "HomeLAN" nocheck
set property "InternetGatewayDevice.LANDevice.1.LANHostConfigManagement.IPIInterface.1.Enable" "1" nocheck
set property "InternetGatewayDevice.LANDevice.1.LANHostConfigManagement.IPIInterface.1.IPIInterfaceAddressingType" "Static" nocheck
set property "InternetGatewayDevice.LANDevice.1.LANHostConfigManagement.IPIInterface.1.IPIInterfaceIPAddress" "192.168.1.1" nocheck
set property "InternetGatewayDevice.LANDevice.1.LANHostConfigManagement.IPIInterface.1.IPIInterfaceSubnetMask" "255.255.255.0" nocheck
set property "InternetGatewayDevice.LANDevice.1.LANHostConfigManagement.IPRouters" "192.168.1.1" nocheck
set property "InternetGatewayDevice.LANDevice.1.LANHostConfigManagement.MaxAddress" "192.168.1.254" nocheck
set property "InternetGatewayDevice.LANDevice.1.LANHostConfigManagement.MinAddress" "192.168.1.2" nocheck
set property "InternetGatewayDevice.LANDevice.1.LANHostConfigManagement.SubnetMask" "255.255.255.0" nocheck
set property "InternetGatewayDevice.Layer2Bridging.Bridge.1.BridgeEnable" "TRUE" nocheck
set property "InternetGatewayDevice.Layer2Bridging.Bridge.1.BridgeName" "brHSI" nocheck
set property "InternetGatewayDevice.Layer2Bridging.Bridge.1.BridgeStandard" "802.1Q" nocheck
set property "InternetGatewayDevice.Layer2Bridging.Bridge.1.VLANID" "10" nocheck
set property "InternetGatewayDevice.Layer2Bridging.Bridge.2.BridgeEnable" "1" nocheck
set property "InternetGatewayDevice.Layer2Bridging.Bridge.2.BridgeName" "brVoIP" nocheck
set property "InternetGatewayDevice.Layer2Bridging.Bridge.2.BridgeStandard" "802.1Q" nocheck
set property "InternetGatewayDevice.Layer2Bridging.Bridge.2.VLANID" "12" nocheck
set property "InternetGatewayDevice.Layer2Bridging.Bridge.3.BridgeEnable" "1" nocheck
set property "InternetGatewayDevice.Layer2Bridging.Bridge.3.BridgeName" "brIPTV" nocheck
set property "InternetGatewayDevice.Layer2Bridging.Bridge.3.BridgeStandard" "802.1Q" nocheck
set property "InternetGatewayDevice.Layer2Bridging.Bridge.3.VLANID" "11" nocheck
set property "InternetGatewayDevice.Layer2Bridging.Bridge.4.BridgeEnable" "1" nocheck
set property "InternetGatewayDevice.Layer2Bridging.Bridge.4.BridgeName" "MC" nocheck

```



```

nocheck
set property "InternetGatewayDevice.WANDevice.1.WANConnectionDevice.1.WANIPConnection.1.ConnectionType"
"IP_Routed" nocheck
set property "InternetGatewayDevice.WANDevice.1.WANConnectionDevice.1.WANIPConnection.1.DHCPClient.
SentDHCPOption.1.Enable" "1" nocheck
set property "InternetGatewayDevice.WANDevice.1.WANConnectionDevice.1.WANIPConnection.1.DHCPClient.
SentDHCPOption.1.Tag" "60" nocheck
set property "InternetGatewayDevice.WANDevice.1.WANConnectionDevice.1.WANIPConnection.1.DHCPClient.
SentDHCPOption.1.Value" "Vk9JUF9OVFAtUkc=" nocheck
set property "InternetGatewayDevice.WANDevice.1.WANConnectionDevice.1.WANIPConnection.1.Enable" "1" nocheck
set property "InternetGatewayDevice.WANDevice.1.WANConnectionDevice.1.WANIPConnection.1.Name" "VoIP_IPoE"
nocheck
set property "InternetGatewayDevice.WANDevice.1.WANConnectionDevice.1.WANIPConnection.2.AddressingType"
"Static" nocheck
set property "InternetGatewayDevice.WANDevice.1.WANConnectionDevice.1.WANIPConnection.2.ConnectionType"
"IP_Routed" nocheck
set property "InternetGatewayDevice.WANDevice.1.WANConnectionDevice.1.WANIPConnection.2.DefaultGateway"
"10.0.0.1" nocheck
set property "InternetGatewayDevice.WANDevice.1.WANConnectionDevice.1.WANIPConnection.2.Enable" "1" nocheck
set property "InternetGatewayDevice.WANDevice.1.WANConnectionDevice.1.WANIPConnection.2.ExternalIPAddress"
"10.10.10.10" nocheck
set property "InternetGatewayDevice.WANDevice.1.WANConnectionDevice.1.WANIPConnection.2.Name" "MC_IPoE" nocheck
set property "InternetGatewayDevice.WANDevice.1.WANConnectionDevice.1.WANIPConnection.2.SubnetMask" "255.0.0.0"
nocheck
set property "InternetGatewayDevice.WANDevice.1.WANConnectionDevice.1.WANIPConnection.2.
X_BROADCOM_COM_IGMPEnabled" "1" nocheck
set property "InternetGatewayDevice.WANDevice.1.WANConnectionDevice.1.WANPPPConnection.1.ConnectionTrigger"
"AlwaysOn" nocheck
set property "InternetGatewayDevice.WANDevice.1.WANConnectionDevice.1.WANPPPConnection.1.ConnectionType"
"IP_Routed" nocheck
set property "InternetGatewayDevice.WANDevice.1.WANConnectionDevice.1.WANPPPConnection.1.Enable" "1" nocheck
set property "InternetGatewayDevice.WANDevice.1.WANConnectionDevice.1.WANPPPConnection.1.IdleDisconnectTime"
"0" nocheck
set property "InternetGatewayDevice.WANDevice.1.WANConnectionDevice.1.WANPPPConnection.1.Name" "HSI_PPP" nocheck
set property "InternetGatewayDevice.WANDevice.1.WANConnectionDevice.1.WANPPPConnection.1.NATEnabled" "1" nocheck

```


. NTP-RG14XXG/NTP-RG14XXG-W

```

set property "InternetGatewayDevice.WANDevice.1.WANConnectionDevice.1.WANPPPConnection.1.Username" "szt" nocheck
set property "InternetGatewayDevice.WANDevice.1.WANConnectionDevice.1.WANPPPConnection.1.Password" "szt" nocheck
set property "InternetGatewayDevice.Services.VoiceService.1.VoiceProfile.1.Line.1.CallingFeatures.CallerIDName"
"111" nocheck
set property "InternetGatewayDevice.Services.VoiceService.1.VoiceProfile.1.Line.1.DirectoryNumber" "111" nocheck
set property "InternetGatewayDevice.Services.VoiceService.1.VoiceProfile.1.Line.1.Enable" "Enabled" nocheck
set property "InternetGatewayDevice.Services.VoiceService.1.VoiceProfile.1.Line.1.SIP.AuthPassword" "111"
nocheck
set property "InternetGatewayDevice.Services.VoiceService.1.VoiceProfile.1.Line.1.SIP.AuthUserName" "111"
nocheck
set property "InternetGatewayDevice.Services.VoiceService.1.VoiceProfile.1.Line.2.CallingFeatures.CallerIDName"
"222" nocheck
set property "InternetGatewayDevice.Services.VoiceService.1.VoiceProfile.1.Line.2.DirectoryNumber" "222" nocheck
set property "InternetGatewayDevice.Services.VoiceService.1.VoiceProfile.1.Line.2.Enable" "Enabled" nocheck
set property "InternetGatewayDevice.Services.VoiceService.1.VoiceProfile.1.Line.2.SIP.AuthPassword" "222"
nocheck
set property "InternetGatewayDevice.Services.VoiceService.1.VoiceProfile.1.Line.2.SIP.AuthUserName" "222"
nocheck
set property "InternetGatewayDevice.Services.VoiceService.1.VoiceProfile.1.SIP.OutboundProxy" "test.ru" nocheck
set property "InternetGatewayDevice.Services.VoiceService.1.VoiceProfile.1.SIP.RegistrarServer" "test.ru"
nocheck
set property "InternetGatewayDevice.Services.VoiceService.1.VoiceProfile.1.SIP.UserAgentDomain" "test.ru"
nocheck

```

. - RS-232



. ONT NTU-1

bridge, ONT VLAN 2149.

ONT NTU-1 (bridge), OLT OMCI ACS.
VLAN switch LTP.

```

SWITCH
LTP-X# switch

SWITCH
LTP-X(switch)# configure

VLAN
LTP-X(switch)(config)# vlan 2149

VLAN front- 0
LTP-X(switch)(config-vlan)# tagged front-port 0

pon-
LTP-X(switch)(config-vlan)# tagged pon-port 0 - 7
LTP-X(switch)(config-vlan)# exit

LTP-X(switch)(config)# commit
LTP-X(switch)(config)# exit
LTP-X(switch)# exit

```

```
* :  
LTP-8 rev.B HW_revision 2v.  
LTP-8 rev. HW_revision 1v.  
LTP-4X rev.B «tagged pon-port 0 – 3».
```

Cross Connect Ports.

```
LTP-X# configure terminal  
  
    Cross-Connect  NTU-  
1  
LTP-X(config)# profile cross-connect NTU1  
  
    bridge  
LTP-X(config-cross-connect)( "NTU1")# bridge  
  
    Cross-connect bridge group 20  
LTP-X(config-cross-connect)( "NTU1")# bridge group 20
```

```
VLAN  
LTP-X(config-cross-connect)( "NTU1")# outer vid 2149  
LTP-X(config-cross-connect)( "NTU1")# exit  
  
    NTU-1  
LTP-X(config)# profile ports NTU1  
  
    0 bridge group 20  
LTP-X(config-ports)( "NTU1")# port 0 bridge group 20  
  
LTP-X(config-ports)( "NTU1")# do commit  
  
LTP-X(config-ports)( "NTU1")# do save
```

ONT NTU-1.

```
LTP-X# configure terminal  
  
    0 ONT ID 3  
LTP-X(config)# interface ont 0/3  
  
    ONT  
LTP-X(config)(if-ont-0/3)# serial 454C545862000078  
  
    ports NTU-1  
LTP-X(config)(if-ont-0/3)# profile ports NTU1  
  
    cross-connect NTU-1  
LTP-X(config)(if-ont-0/3)# service 0 profile cross-connect NTU1  
  
    DBA  
LTP-X(config)(if-ont-0/3)# service 0 profile dba dba-00  
  
LTP-X(config)(if-ont-0/3)# do commit  
  
LTP-X(config)(if-ont-0/3)# do save
```

ONT NTU-1 VLAN TRUNK.

8 VLAN trunk ONT NTU-1.

VLAN 100 200.

VLAN switch LTP.

```
SWITCH
LTP-X# switch

SWITCH
LTP-X.switch) # configure
```

```
VLAN
LTP-X.switch)(config)# vlan 100,200

VLAN front- 0
LTP-X.switch)(config-vlan)# tagged front-port 0

pon-*
LTP-X.switch)(config-vlan)# tagged pon-port 0 - 7

LTP-X.switch)(config-vlan)# exit
LTP-X.switch)(config)# commit
LTP-X.switch)(config)# exit
LTP-X.switch)# exit
```

```
* :
LTP-8 rev.B HW_revision 2v.
LTP-8 rev. HW_revision 1v.
LTP-4X rev.B «tagged pon-port 0 – 3».
```

Cross Connect Ports.

```
LTP-X# configure terminal

Cross-Connect NTU-1
LTP-X(config)# profile cross-connect NTU100

bridge
LTP-X(config-cross-connect)("NTU100")# bridge

Cross-connect bridge group 20
LTP-X(config-cross-connect)("NTU100")# bridge group 20

VLAN
LTP-X(config-cross-connect)("NTU100")# outer vid 100

VLAN
LTP-X(config-cross-connect)("NTU100")# user vid 100
LTP-X(config-cross-connect)("NTU100")# exit

Cross-Connect NTU-1
LTP-X(config)# profile cross-connect NTU200

Cross-connect bridge group 20
LTP-X(config-cross-connect)("NTU200")# bridge group 20

VLAN
LTP-X(config-cross-connect)("NTU200")# outer vid 200

VLAN
LTP-X(config-cross-connect)("NTU200")# user vid 200
LTP-X(config-cross-connect)("NTU200")# exit
```

```

NTU-1
LTP-X(config)# profile ports NTU1

  0 bridge group 20
LTP-X(config-ports)( "NTU1")# port 0 bridge group 20

LTP-X(config-ports)( "NTU1")# do commit

LTP-X(config-ports)( "NTU1")# do save

```

ONT NTU-1.

```

LTP-X# configure terminal

  0 ONT ID
3
LTP-X(config)# interface ont 0/3

  ONT
LTP-X(config)(if-ont-0/3)# serial 454C545862000078

  ports NTU1
LTP-X(config)(if-ont-0/3)# profile ports NTU1

  cross-connect NTU-1
LTP-X(config)(if-ont-0/3)# service 0 profile cross-connect NTU100

  DBA
LTP-X(config)(if-ont-0/3)# service 0 profile dba dba-00

  cross-connect NTU-1
LTP-X(config)(if-ont-0/3)# service 1 profile cross-connect NTU200

  DBA
LTP-X(config)(if-ont-0/3)# service 1 profile dba dba-00

LTP-X(config)(if-ont-0/3)# do
commit

```

. ONT SFP-ONU

bridge, ONT VLAN 2149.

ONT SFP-ONU (bridge), OLT OMCI ACS.
VLAN switch LTP.

```

        SWITCH
LTP-X# switch

        SWITCH
LTP-X(switch)# configure

        VLAN
LTP-X(switch)(config)# vlan 2149

        VLAN front- 0
LTP-X(switch)(config-vlan)# tagged front-port 0

        pon-*
LTP-X(switch)(config-vlan)# tagged pon-port 0 - 7
LTP-X(switch)(config-vlan)# exit

LTP-X(switch)(config)# commit
LTP-X(switch)(config)# exit
LTP-X(switch)# exit

```

```

* :
LTP-8 rev.B HW_revision 2v.
LTP-8 rev. HW_revision 1v.
LTP-4X rev.B «tagged pon-port 0 – 3».

```

Cross Connect Ports.

```

LTP-X# configure terminal

        Cross-Connect NTU-1
LTP-X(config)# profile cross-connect SFP

        bridge
LTP-X(config-cross-connect)("NTU1")# bridge

        Cross-connect bridge group 20
LTP-X(config-cross-connect)("NTU1")# bridge group 20

```

```

        VLAN
LTP-X(config-cross-connect)("NTU1")# outer vid 2149
LTP-X(config-cross-connect)("NTU1")# exit

        SFP-ONU
LTP-X(config)# profile ports SFPONU

        0 bridge group 20
LTP-X(config-ports)("NTU1")# port 0 bridge group 20

LTP-X(config-ports)("NTU1")# do commit

LTP-X(config-ports)("NTU1")# do save

```

ONT SFP-ONU.

```

LTP-X# configure terminal

    0 ONT ID 3
LTP-X(config)# interface ont 0/3

    ONT
LTP-X(config)(if-ont-0/3)# serial 454C545862000078

    ports SFPONU
LTP-X(config)(if-ont-0/3)# profile ports SFPONU

    cross-connect SFP-ONU
LTP-X(config)(if-ont-0/3)# service 0 profile cross-connect SFP

    DBA
LTP-X(config)(if-ont-0/3)# service 0 profile dba dba-00

LTP-X(config)(if-ont-0/3)# do commit

LTP-X(config)(if-ont-0/3)# do save

```

ONT SFP-ONU VLAN TRUNK

```

8 VLAN trunk ONT SFP-ONU.

VLAN 100 200.

VLAN switch LTP.

```

```

SWITCH
LTP-X# switch

SWITCH
LTP-X(switch)# configure

```

```

VLAN
LTP-X(switch)(config)# vlan 100,200

VLAN front- 0
LTP-X(switch)(config-vlan)# tagged front-port 0

pon-
LTP-X(switch)(config-vlan)# tagged pon-port 0 - 7

LTP-X(switch)(config-vlan)# exit
LTP-X(switch)(config)# commit
LTP-X(switch)(config)# exit
LTP-X(switch)# exit

```

Cross Connect Ports.

```
LTP-X# configure terminal

    Cross-Connect SFP-ONU
LTP-X(config)# profile cross-connect SFP100

    bridge
LTP-X(config-cross-connect)("SFP100")# bridge

    Cross-connect bridge group 20
LTP-X(config-cross-connect)("SFP100")# bridge group 20

    VLAN
LTP-X(config-cross-connect)("SFP100")# outer vid 100

    VLAN
LTP-X(config-cross-connect)("SFP100")# user vid 100
LTP-X(config-cross-connect)("SFP100")# exit

    Cross-Connect SFP-ONU
LTP-X(config)# profile cross-connect SFP200

    Cross-connect bridge group 20
LTP-X(config-cross-connect)("SFP200")# bridge group 20

    VLAN
LTP-X(config-cross-connect)("SFP200")# outer vid 200

    VLAN
LTP-X(config-cross-connect)("SFP200")# user vid 200
LTP-X(config-cross-connect)("SFP200")# exit

    SFP-ONU
LTP-X(config)# profile ports SFPONU

    0 bridge group 20
LTP-X(config-ports)("SFPONU")# port 0 bridge group 20

LTP-X(config-ports)("SFPONU ")# do commit
```

```
LTP-X(config-ports)("SFPONU ")# do save
```

ONT SFP-ONU.

```

LTP-X# configure terminal

    0 ONT ID 3
LTP-X(config)# interface ont 0/3

    ONT
LTP-X(config)(if-ont-0/3)# serial 454C545862000078

    ports SFPONU
LTP-X(config)(if-ont-0/3)# profile ports SFPONU

    cross-connect SFP-ONU
LTP-X(config)(if-ont-0/3)# service 0 profile cross-connect SFP100

    DBA
LTP-X(config)(if-ont-0/3)# service 0 profile dba dba-00

    cross-connect SFP-ONU
LTP-X(config)(if-ont-0/3)# service 1 profile cross-connect SFP200

    DBA
LTP-X(config)(if-ont-0/3)# service 1 profile dba dba-00

LTP-X(config)(if-ont-0/3)# do commit

```

ONT SFP-ONU VLAN TRUNK, VLAN Selective-tunnel VLAN Tunnel

3.26.0 .. trunk SFP-ONU.

uplink OLT VLAN 300 (multicast) QinQ VLAN 1100 1200 (), , OLT SFP-ONU.

OLT .

- 1. .

```

LTP-X(config)# vlan 300,1100,1200
LTP-X(config-vlan-range)# tagged pon-port 0
LTP-X(config-vlan-range)# front-port 0
LTP-X(config-vlan-range)# commit

```

- 2. cross-connect.

```

LTP-X(config)# profile cross-connect cc-tunnel
LTP-X(config-cross-connect)("cc-tunnel")# bridge
LTP-X(config-cross-connect)("cc-tunnel")# bridge group 10
LTP-X(config-cross-connect)("cc-tunnel")# tag-mode tunnel
LTP-X(config-cross-connect)("cc-tunnel")# exit
LTP-X(config)# profile cross-connect "cc-selecttunnel"
LTP-X(config-cross-connect)("cc-selecttunnel")# bridge
LTP-X(config-cross-connect)("cc-selecttunnel")# bridge group 10
LTP-X(config-cross-connect)("cc-selecttunnel")# tag-mode selective-tunnel
LTP-X(config-cross-connect)("cc-selecttunnel")# exit
LTP-X(config)# profile cross-connect "cc-single"
LTP-X(config-cross-connect)("cc-single")# bridge
LTP-X(config-cross-connect)("cc-single")# bridge group 10
LTP-X(config-cross-connect)("cc-single")# user vid 300
LTP-X(config-cross-connect)("cc-single")# exit

```

- 3. ports.

```

LTP-X(config)# profile ports bridge-10
LTP-X(config-ports)("bridge-10")# port 0 bridge group 10

```

- 4. address-table, VLAN, gpon-.

```
LTP-X(config)# profile address-table at-tunnel
LTP-X(config-address-table)(“at-tunnel”)# s-vlan 1100 use c-vlan
LTP-X(config-address-table)(“at-tunnel”)# s-vlan 1200 use c-vlan
LTP-X(config-address-table)(“at-tunnel”)# exit
LTP-X(config)# interface gpon-port 0
LTP-X(config)(if-gpon-0)# profile address-table at-tunnel
```

- 5. SFP-ONU, .

```
LTP-X(config)# interface ont 0/0
LTP-X(config)(if-ont-0/0)# serial "454C545300000001"
LTP-X(config)(if-ont-0/0)# service 0 profile cross-connect cc-tunnel dba dba-00
LTP-X(config)(if-ont-0/0)# service 1 profile cross-connect cc-selecttunnel dba dba-00
LTP-X(config)(if-ont-0/0)# service 2 profile cross-connect cc-single dba dba-00
LTP-X(config)(if-ont-0/0)# profile ports "bridge-10"
LTP-X(config)(if-ont-0/0)# service 0 custom svvid 1100
LTP-X(config)(if-ont-0/0)# service 1 custom svvid 1200
LTP-X(config)(if-ont-0/0)# service 1 selective-tunnel uavid 201-203
LTP-X(config)(if-ont-0/0)# service 2 custom svvid 300
```

ONU/GPON-

ONT

ONT	
UNACTIVATED	ONT
ALLOCATED	ONT
AUTHINPROGRESS	ONT
AUTHFAILED	
AUTHOK	
PRECONFIG	ONT
CFGINPROGRESS	ONT
CFGFAILED	
OK	ONT
BLOCKED	ONT
MIBRESET	MIB ONT
FAILED	ONT
FWUPDATING	ONT
DISABLED	ONT

GPON-

INITED	
CFGINPROGRESS	
CFGFAILED	
OK	
FAILED	

DISABLED	
----------	--

« «» :

: <https://eltex-co.ru/support/>

Servicedesk: https://servicedesk_eltex-co_ru

« «», , .

: <https://eltex-co.ru/>

: <https://eltex-co.ru/forum>

: https://docs_eltex-co_ru/display/EKB/Eltex+Knowledge+Base

: <https://eltex-co.ru/support/downloads>