

- archive
- auto
- banner exec
- banner login
- boot host auto-config
- boot host auto-update
- boot system
- by-commit
- commit
- confirm
- copy
- count-backup
- delete
- dir
- merge
- path
- restore
- rollback
- save
- show bootvar
- show boot-licence
- show candidate-config
- show configuration changes
- show crypto certificates
- show licence
- show running-config
- show storage-devices
- show usb
- show version
- time-period
- type

archive

(no) .

[no] archive

15

CONFIG

:

```
esr(config)# archive  
esr(config-archive)#
```

auto

/ (time-period).

(no) .

[no] auto

15

CONFIG-ARCHIVE

```
:  
esr(config-archive)# auto
```

banner exec

,
(no) ,

```
banner exec <BUNNER>  
no banner exec
```

```
<BUNNER>- , 2047 .
```

10

CONFIG

```
:  
esr(config)# banner exec "  
----- Hello! This is an Eltex router.  
----- Unauthorized configuration changes are prosecuted by the law of the  
Russian Federation. -----"  
-----
```

banner login

```
,  
  
banner login <BUNNER>  
no banner login
```

```
<BUNNER>- , 2047 .
```

10

CONFIG

```
esr(config)# banner login "----- Hello! This is an Eltex router.  
----- \n----- Unauthorized connection is prosecuted by the law of the Russian Federation.  
-----"
```

boot host auto-config

```
DHCP Option 54 (IP- TFTP-) 67 ( ).  
(no)    DHCP Option 66 67.
```

```
[no] boot host auto-config
```

10

CONFIG

```
:
```

```
esr(config)# boot host auto-config
```

boot host auto-update

```
DHCP Option 54 (IP- TFTP-) FILE DHCP OFFER. boot host auto-config,  
(no)    DHCP Option 150 67.
```

```
[no] boot host auto-update
```

10

CONFIG

```
:
```

```
esr(config)# boot host auto-update
```

boot system

boot system <IMAGE>

<IMAGE> – , :

- image-1 – ;
- image-2 – ;

15

ROOT

```
esr# boot system image-2
```

by-commit

(no)

[no] by-commit

15

CONFIG-ARCHIVE

```
esr(config-archive)# by-commit
```

commit

() . RUNNING- CANDIDATE. , «confirm» , (600 , [system config-confirm timeout](#)).

commit

10

ROOT

CHANGE-EXPIRED-PASSWORD

:

```
esr# commit
```

confirm

```
  . ( 600 , system config-confirm timeout) «commit» ,
```

confirm

10

ROOT

CHANGE-EXPIRED-PASSWORD

:

```
esr# confirm
```

copy

copy <SOURCE> <DESTINATION>

<SOURCE> - , :

- tftp://<ip>[<port>]:<path> - TFTP-, :
 - <ip> - IP- TFTP-;
 - <port> - , TFTP-, IP- «#» «:»;
 - <path> - TFTP-.
- tftp://<ipv6>[%<interface>][<port>]:<path> - TFTP-, :
 - <ipv6> - IPv6- TFTP-;
 - <interface> - link-local ;
 - <port> - , TFTP-, IPv6- '# ' (IPv6- «[]»);
 - <path> - TFTP-.
- ftp://[<user>[:<password>]@]<ip>[<port>]:<path>
 - <ip> - IP- FTP-;
 - <user> - (ip ftp client username, ip ftp client username);
 - <password> - (ip ftp client password, ip ftp client password);
 - <port> - , TFTP-, IP- «#» «:»;
 - <path> - FTP-.
- ftp://[<user>[:<password>]@]<ipv6>[%<interface>][<port>]:<path>


```
esr# copy tftp://10.100.100.1:/esr.cfg system:candidate-config
```

2

```
esr# copy tftp://10.100.100.1:/crl.pem system:certificate/crl/crl.pem
```

count-backup

(no) .

count-backup <NUM>

no count-backup

<NUM> – . [1..100].

1

15

CONFIG-ARCHIVE

```
:  
esr(config-archive)# count-backup 20
```

delete

...

delete <FILE>

<FILE> – , ():

- flash:backup/FILE – ;
- flash:critlog/FILE – ;
- flash:data/FILE – ;
- flash:syslog/FILE – , ;
- tmpsys:syslog/FILE – , ;
- certificate/ca/FILE – ;
- certificate/dh/FILE – -;
- certificate/server_key/FILE – IPsec/OpenVPN ;
- certificate/server_crt/FILE – IPsec/OpenVPN ;
- certificate:client-key/FILE – OPENVPN-;
- certificate:client-crt/FILE – OPENVPN-;
- certificate/ta/FILE – ;
- certificate/crl/FILE – ;
- system:licence – , ;
- system:boot-licence – , ;
- usb://usb_name/FILE
 - usb_name – USB- "show storage-devices" (. [show storage-devices](#));

- <FILE> – USB-.
- mmc://mmc_name:/<FILE> (ESR-10/12V/12VF/14VF)
 - mmc_name – MMC-. "show storage-devices" (. [show storage-devices](#));
 - <FILE> – MMC-.

15

ROOT

:

```
esr# delete system:certificate/dh/dh.key
```

dir

(USB/MM) .

```
dir <PATH>
{ usb://<USB-device-name>/<PATH> | mmc://<MMC-device-name>/<PATH> | flash:backup/FILE | flash:data/FILE }
```

<PATH> – . :

- flash:critlog/ – ;
- flash:syslog/ – , ;
- flash:backup/ – ;
- flash:data/ – ;
- tmpsys:syslog/ – , ;
- certificate/ca/ – ;
- certificate/dh/ – -;
- certificate/ta/ – ;
- certificate/crl/ – ;
- certificate/server_key/ – IPsec/OpenVPN ;
- certificate/server_crt/ – IPsec/OpenVPN ;
- certificate:client-key/ – OPENVPN-;
- certificate:client-crt/ – OPENVPN-;
- usb://usb_name:/PATH
 - usb_name – USB-. "show storage-devices" (. [show storage-devices](#));
 - <PATH> – USB-.
- mmc://mmc_name:/PATH (ESR-10/12V/12VF/14VF)
 - mmc_name – MMC-. "show storage-devices" (. [show storage-devices](#));
 - <PATH> – MMC-.

<USB-device-name> – USB-. show storage-devices usb, [show storage-devices](#).

<MMC-device-name> – MMC-. show storage-devices mmc, [show storage-devices](#).

- flash:backup/FILE – ;
- flash:data/FILE – ;

<PATH> – USB/MMC-.

flash:backup/FILE – ;

flash:data/FILE – ;

1

ROOT

:

- <path> – TFTP-;
- https://[ca/<CA-FILE>][:server-crt/<SC-FILE>][:server-key/<SK-FILE>]@<ip>[<port>]:<path> – HTTPS-, :
 - <CA-FILE> – ;
 - <SC-FILE> – ;
 - <SK-FILE> – ;
 - <ip> – IP- HTTP-;
 - <port> – , HTTPS-, IP- «#» «:»;
 - <path> – HTTP-;
- https://[ca/<CA-FILE>][:server-crt/<SC-FILE>][:server-key/<SK-FILE>]@<ipv6>[%<interface>][<port>]:<path> – HTTPS-, :
 - <CA-FILE> – ;
 - <SC-FILE> – ;
 - <SK-FILE> – ;
 - <ipv6> – IPv6- HTTPS-;
 - <interface> – link-local ;
 - <port> – , HTTP-, IPv6- '# '!(IPv6- «[]»);
 - <path> – TFTP-;
- flash:data/FILE – .

15

ROOT

```
esr# merge tftp://10.100.100.1/esr.cfg system:candidate-config
```

path

```
        .
        .
(no) .
```

```
path <PATH>
no path
```

```
<PATH> – tftp/ftp/sftp/scp :
```

- tftp://<ip>[<port>]:<path> – TFTP-;
 - <ip> – IP- TFTP-;
 - <port> – , TFTP-, IP- «#» «:»;
 - <path> – TFTP-;
- tftp://<ipv6>[%<interface>][<port>]:<path> – TFTP-,:
 - <ipv6> – IPv6- TFTP-;
 - <interface> – link-local ;
 - <port> – , TFTP-, IPv6- '# '!(IPv6- «[]»);
 - <path> – TFTP-;
- ftp://[<user>[:<password>]@]<ip>[<port>]:<path>
 - <ip> – IP- FTP-;
 - <user> – (ip ftp client username, ip ftp client username);
 - <password> – (ip ftp client password, ip ftp client password);
 - <port> – , TFTP-, IP- «#» «:»;
 - <path> – FTP-;
- ftp://[<user>[:<password>]@]<ipv6>[%<interface>][<port>]:<path>
 - <ipv6> – IPv6- FTP-;
 - <interface> – link-local ;
 - <user> – (ip ftp client username, ip ftp client username);
 - <password> – (ip ftp client password, ip ftp client username);
 - <port> – , TFTP-, IPv6- '# '!(IPv6- «[]»);
 - <path> – FTP-;
- sftp://[<user>[:<password>]@]<ip>[<port>]:<path>
 - <ip> – IP- FTP-;
 - <user> – (ip sftp client username, ip sftp client username);
 - <password> – (ip sftp client password, ip sftp client password);
 - <port> – , TFTP-, IP- «#» «:»;
 - <path> – FTP-;

- sftp://[<user>[:<password>]@]<ipv6>[%<interface>][<port>]:<path>
 - <ipv6> – IPv6- FTP-;
 - <interface> – link-local ;
 - <user> – (ip sftp client username, ip sftp client username);
 - <password> – (ip sftp client password, ip sftp client password);
 - <port> – , TFTP-, IPv6- '# ' (IPv6- «[]»);
 - <path> – FTP-.
- scp://[<user>:<password>@]<ip>[<port>]:<path>
 - <ip> – IP- ;
 - <user> – (ip ssh client username, ip ssh client username);
 - <password> – (ip ssh client password, ip ssh client password);
 - <port> – , TFTP-, IP- «#» «:»;
 - <path> – .
- scp://[<user>:<password>@]<ipv6>[%<interface>][<port>]:<path>
 - <ipv6> – IPv6- ;
 - <interface> – link-local ;
 - <user> – (ip ssh client username, ip ssh client username);
 - <password> – (ip ssh client password, ip ssh client password);
 - <port> – , TFTP-, IPv6- '# ' (IPv6- «[]»);
 - <path> – .

15

CONFIG-ARCHIVE

```
:  
esr(config-archive)# path tftp://10.10.10.1:/esr-1000/config
```

restore

```
, . . . «confirm». «restore» .
```

restore

10

ROOT

```
:  
esr# restore
```

rollback

```
. CANDIDATE . «commit».
```

rollback

10

ROOT

```
:  
esr# rollback
```

save

CANDIDATE

save

10

ROOT

```
:  
esr# save
```

Flash- .

show bootvar

show bootvar

1

ROOT

esr# show bootvar		Date	Status	After reboot
Image	Version			
1	1.0.7 build 119[5cd22b8]	date 22/12/2015 time 18:00:47	Not Active	
2	1.0.7 build 119[5cd22b8]	date 22/12/2015 time 18:00:47	Active	*

show boot-licence

show boot-licence

5

ROOT

:

```
esr# show boot-licence
Licence information
-----
Name: Eltex
Version: 1.0
Type: ESR-1000
S/N: NP01000530
MAC: A8:F9:4B:AA:44:BB
Features:
KSS - Kaspersky Security System
```

show candidate-config

, («commit»).

show candidate-config [full] [<SECTION>]

full – , .

<SECTION> – :

- aaa – , ;
- access-list – ;
- bridges – ;
 - [<NUM>] – .
- channel-group – ;
- clock – NTP-;
- dhcp – DHCP-, Relay-;
- content-provider – ;
- dual-homing – Dual Homing ¹ ;
- extended – ;
- hostname – ;
- interfaces [<IF>] – :

- <IF> – , .
- ip-address – IP-;
- ipv6 [<SUBSECTION>] – IPv6:
 - address – IPv6-;
 - dhcp [<SUBSECTION>] – IPv6 DHCP-;
 - client – IPv6 DHCP-;
 - relay – IPv6 DHCP Relay-;
 - server – IPv6 DHCP-.
 - routing [<SUBSECTION>] – IPv6-:
 - bfd – IPv6 BFD;
 - bgp – IPv6 BGP;
 - ospf – OSPFv3;
 - prefix-lists – IPv6 -;
 - rip – RIP;
 - static – .
 - vrrp – IPv6 VRRP-.
- dialplan – ;
- lldp – LLDP;
- mac-address-table – MAC- ¹ ;
- mailservers – ;
- mdns – mDNS;
- mirroring – ¹ ;
- mpls – MPLS;
- mdns – mDNS;
- multiwan – WAN-;
- nat [<SUBSECTION>] – NAT:
 - source – Source NAT;
 - destination – Destination NAT;
 - alg – NAT.
- netflow – Netflow ;
- object-groups [<TYPE> [<NAME>]] – ;
 - <TYPE> – , :
 - content-filter;
 - email;
 - network;
 - address-port;
 - application;
 - mac;
 - service;
 - url.
 - <NAME> – .
- port-security – Port Security ¹ ;
- qos – QoS;
- remote-access [<SUBSECTION>] – L2TP over IPsec PPTP-;
 - l2tp – L2TP over IPsec-;
 - pptp – PPTP-;
 - openvpn – OpenVPN-;
- remote-client – (SSH, Telnet, etc.);
- rmon – RMON;
- routing [<SUBSECTION>] – :
 - bfd – BFD;
 - bgp – BGP;
 - isis – IS-IS;
 - key-chains – ;
 - ospf – OSPF;
 - prefix-list – -;
 - rip – RIP;
 - route-maps –
 - [<RM-NAME>] – .
 - static – .
- security [<SUBSECTION>] – IPsec VPN Firewall;
 - antis팸 – «»;
 - ike – IKE;
 - ipsec – IPsec
 - zone – Firewall;
 - zone-pair – Firewall;
- sip – SIP;
 - profile – SIP-;
 - service – SIP-;
- sflow – sFlow ;
- snmp – SNMP-;
- spanning-tree – Spanning Tree;
- sla – IP SLA
- system – ;
- syslog – Syslog;
- tracks – Tracking-;
- tunnels [<TYPE> [<NUM>]] – ;
 - <TYPE> – , :
 - gre – GRE-;

- ip4ip4 – IPv4 over IPv4-;
- l2tp – L2TP-;
- l2tpv3 – L2TPv3-;
- lt – ;
- softgre – SoftGRE- ¹;
- vti – VTI-;
- pptp – PPTP-;
- pppoe – PPPoE-;
- l2tp – L2TP-;
- openvpn – OPENVPN-;
- <NUM> –
- vlans – VLAN;
- voice – ;
- vrf – VRF;
- vrrp – VRRP-;
- wisla – wiSLA;
- wireless-controller – Wi-Fi ;
- zabbix – Zabbix .



1

ESR-1000.

10

ROOT

:

```
esr# show candidate-config
ntp enable
ntp broadcast-client enable
syslog max-files 3
syslog file-size 512
syslog file default info
vlan 2
exit
security zone trusted
exit
security zone untrusted
exit
object-group service telnet
  port-range 23
exit
object-group service ssh
  port-range 22
exit
object-group service dhcp_server
  port-range 67
exit More? Enter - next line; Space - next page; Q - quit; R - show the rest.
```

show configuration changes

show configuration changes [<CONFIG> < CONFIG>]

<CONFIG> – . :

- candidate-config;
- running-config;
- factory-config;
- default-config;

- flash:backup/FILE.

```
<CONFIG> running-config candidate-config.
```

10

ROOT

:

```
esr(config-)# show configuration changes
+ interface gigabitethernet 1/0/1.100
+   ip firewall disable
+   ip address 10.54.22.1/24
+ exit
```

show crypto certificates

```
show crypto certificates [ <CERTIFICATE-TYPE> ]
```

```
<CERTIFICATE-TYPE>- , :
```

- ca - ;
- crl - ;
- dh - -;
- server-crt - ;
- server-key - ;
- client-crt - ;
- client-key - ;
- ta - HMAC-.

15

ROOT

:

```
esr# show crypto certificates
Type          Total
-----  -----
ca              3
dh              1
server key      2
server crt      1
ta              1
crl             1
```

show licence

:

```
show licence
```

5

ROOT

:

```
esr# show licence
Licence information
-----
Name: X-Telecom
Version: 1.0
Type: ESR-1000
S/N: NP01000046
MAC: A8:F9:4B:AA:03:20
Features:
    DHCP - Dynamic Host Configuration Protocol
    IDS - Empty description
    SWUTIL - View interface's utilization
```

show running-config

```
show running-config [<SECTION>] [ full ]
```

<SECTION> – , [show candidate-config](#).

full – , .

10

ROOT

:

```
esr# show running-config syslog
syslog max-files 3
syslog file-size 512
syslog file default info
syslog console info
```

show storage-devices

(USB/MMC).

```
show storage-devices { usb | mmc }
```

usb – USB- .

mmc – SD/MMC .

1

ROOT

:

```
esr# show storage-devices mmc
Name          Total, MB   Used, MB   Free, MB
-----        -----      -----      -----
EF28-D074    99.79      72.64      27.15
```

show usb

USB-.

show usb

:

1

ROOT

:

```
esr-1000# show usb
USB device  Vendor      Product ID      Product version
-----      -----      -----      -----
1-1         Flash       USB Disk        6.80
```

show version

show version

1

ROOT

```
:  
  
esr# show version  
Boot version:  
  1.0.7.16 (date 18/11/2015 time 13:40:59)  
SW version:  
  1.0.7 build 17[d9bdbda] (date 21/11/2015 time 18:06:41)  
HW version:  
  1v7
```

time-period

```
,  
  
(no) .
```

```
time-period <TIME>  
no time-period
```

```
<TIME>- , [1..35791394].
```

```
720
```

```
15
```

CONFIG-ARCHIVE

```
:  
  
esr(config-archive)# time-period 1440
```

type

```
(no) .
```

```
type <TYPE>  
no type  
  
<TYPE>- . :  


- local - flash:backup/ "config_YYYYMMDD_HHMMSS;" :
  - YYYY - , ;
  - MM - , ;
  - DD - , ;
  - HH - , ;
  - MM - , ;
  - SS - , ;
- remote - ;
- both - flash:backup .

```

remote

15

CONFIG-ARCHIVE

:

```
esr(config-archive)# type both
```