

v1.16_ SoftWLC -

- SoftWLC :
- 8
 - CPU >= 2200MHz
 - >= 35Gb
 -
 - Ubuntu Server 16.04

.
.
-.

- eltex-softwlc-helper-mos_1.XX.sh .
:

```
vagrant@ubuntu-xenial:~$ wget http://archive.eltex.org/wireless/help/softwlc-1.XX/eltex-softwlc-helper-mos_1.XX.sh
--2019-04-29 08:30:24-- http://archive.eltex.org/wireless/help/softwlc-1.XX/eltex-softwlc-helper-mos_1.XX.sh
Resolving archive.eltex.org (archive.eltex.org)... 172.16.0.68
Connecting to archive.eltex.org (archive.eltex.org)|172.16.0.68|80... connected.
HTTP request sent, awaiting response... 200 OK
Length: 25615 (25K) [text/x-sh]
Saving to: 'eltex-softwlc-helper-mos_1.XX.sh'

eltex-softwlc-helper-mos_1 100%[=====>] 25,01K --KB/s in 0,02s

2019-04-29 08:30:24 (1,61 MB/s) - 'eltex-softwlc-helper-mos_1.XX.sh' saved [25615/25615]
```

eltex-softwlc-helper-mos_1.XX.sh :

```
vagrant@ubuntu-xenial:~$ chmod +x ./eltex-softwlc-helper-mos_1.XX.sh
```

:

```
vagrant@ubuntu-xenial:~$ sudo ./eltex-softwlc-helper-mos_1.XX.sh
Platform : x86_64
Repository: http://archive.eltex-co.ru/wireless
Java vendor: openjdk
Ubuntu distrib code name: xenial
--2019-04-29 08:33:06-- http://archive.eltex-co.ru/wireless/nginx/conf/softwlc_1.XX/nginx.conf
Resolving archive.eltex-co.ru (archive.eltex-co.ru)... 172.16.0.68
Connecting to archive.eltex-co.ru (archive.eltex-co.ru)|172.16.0.68|80... connected.
HTTP request sent, awaiting response... 200 OK

.....
```

:

```
Installation of Eltex SoftWLC finished
URLs of SoftWLC components:
Eltex.EMS GUI: http://localhost:8080/ems/jws
login: admin
password: <empty>

Portal constructor: http://localhost:8080/epadmin
login: admin
password: password

Wi-Fi customer cabinet: http://localhost:8080/wifi-cab
login: admin
password: password
```

EMS Java Web Start , Oracle Java.

:

```
http://<ip address SoftwLC>:8080/ems/jws/
```

jnlp. Java Web Start.



Oracle Java 8

EMS Java Control Panel .

. - .

```
# MySQL
export ANSWER_SOFTWLC_MYSQL_USER=root

# MySQL
export ANSWER_SOFTWLC_MYSQL_PASSWORD=root

# SoftwLC
export ANSWER_AUTH_SERVICE_ADMIN_USER=admin

# SoftwLC
export ANSWER_AUTH_SERVICE_ADMIN_PASSWORD=password

# SoftwLC (softwlc_service)
export ANSWER_SOFTWLC_SERVICE_USER_PASSWORD=softwlc
```

SWLC:

[v1.16_](#) /