

**WOP-12ac-LR** - [https://eltex-co.ru/catalog/wi-fi\\_access\\_points/wop-12ac-lr/](https://eltex-co.ru/catalog/wi-fi_access_points/wop-12ac-lr/)

**WOP-2ac-LR2** - [https://eltex-co.ru/catalog/wi-fi\\_access\\_points/bazovaya\\_stantsiya\\_wop-2ac-lr2/](https://eltex-co.ru/catalog/wi-fi_access_points/bazovaya_stantsiya_wop-2ac-lr2/)

**WB-2P-LR2** - [https://eltex-co.ru/catalog/wi-fi\\_access\\_points/abonentskaya\\_stantsiya\\_wb-2p-lr2/](https://eltex-co.ru/catalog/wi-fi_access_points/abonentskaya_stantsiya_wb-2p-lr2/)

- 40 . , .
- n/ac .
- Fixed Multicast Rate = 54 /.
- OBSS Coex = Off.
- DFS = Off.
- 80 ( ).
- Station Isolation VAP.
- Global Isolation Wireless Settings.
- Wireless Multicast Forwarding (WMF) VAP, IPTV ( ). Manage/Wireless Multicast Forwarding.
- Arp Suppression. Manage/Radio/Advanced settings/Arp Suppression.

6. 2-3 , ACK timeout, . **WB-2P-LR5 WOP-2P-LR5** 2, **WB-1P-LR WOP-12ac-LR** - 3.

WOP-12ac-LR . :

, . - . - 255. :

```
set radio wlan odap-ack-timeout 98
set radio wlan odap-slot-time 9
save-running
```