


IP Unnumbered MES23xx/33xx/35xx/5324



IP Unnumbered IP IP- .

```
1 gi0/1, ip 1.1.1.2 /24 default-gateway 1.1.1.1
2 gi0/2, ip 1.1.1.3 /24 default-gateway 1.1.1.1
3 gi0/3, ip 1.1.1.4 /24 default-gateway 1.1.1.1
4 gi0/4, ip 1.1.2.2 /24 default-gateway 1.1.2.1
```

:

```
condole(config)# vlan database
condole(config-vlan)# vlan 2-4
condole(config-vlan)# exit

condole(config)# interface gigabitethernet 1/0/2
condole(config-if)# switchport access vlan 2

condole(config)# interface gigabitethernet 1/0/3
condole(config-if)# switchport access vlan 3

condole(config)# interface gigabitethernet 1/0/4
condole(config-if)# switchport access vlan 4

condole(config)# interface vlan 1
condole(config-if)# ip address 1.1.1.1 255.255.255.0
condole(config-if)# no ip address dhcp

condole(config)# interface vlan 2
condole(config-if)# ip unnumbered vlan 1

condole(config)# interface vlan 3
condole(config-if)# ip unnumbered vlan 1

condole(config)# interface vlan 4
condole(config-if)# ip address 1.1.2.1 255.255.255.0

condole(config)# no ip arp proxy disable
```

: IGMP Proxy PIM IP Unnumbered .

DHCP Relay, VLAN:

```
condole(config)# interface vlan 2
condole(config-if)# ip unnumbered Loopback 1
condole(config-if)# ip dhcp relay enable

condole(config)# interface vlan 3
condole(config-if)# ip unnumbered Loopback 1
condole(config-if)# ip dhcp relay enable
```

