

(LBD) MES14xx, MES24xx, MES3400-xx, MES37

errdisable.

```
console(config)# loopback-detection enable
```

```
console(config-if)# loopback-detection enable
```

lbd- :

```
console(config)# loopback-detection interval <1..60>
```

30 .

errdisable :

```
console(config)# errdisable recovery cause loopback-detection
```