

// TFTP- MES14xx, MES24xx, MES3400-xx, MES37

, / CLI (HyperTerminal) Telnet SSH, .

TFTP CLI :

console# **copy tftp:// xxx.xxx.xxx.xxx/ *File_Name* startup-config**

,

- xxx.xxx.xxx.xxx – IP- TFTP, ;
- File_Name – ;

Enter.

TFTP CLI :

console# **copy startup-config tftp:// xxx.xxx.xxx.xxx/ *File_Name***

,

- xxx.xxx.xxx.xxx – IP- TFTP, ;
- File_Name – ;

Enter.