

DNS

- domain ip host
- domain lookup enable
- domain name
- domain name-server

domain ip host

DNS-.

(no) .

```
[no] domain ip host <NAME> <IP>
```

<NAME> – , 255 .

<IP> – IP- , AAA.BBB.CCC.DDD, [0..255].

10

CONFIG

:

```
esr(config)# domain ip host eltex.loc 172.16.0.3
```

domain lookup enable

DNS-.

(no) DNS-.

```
[no] domain lookup enable [ vrf <VRF> ]
```

<VRF> – VRF, 31 , DNS-.

10

CONFIG

:

```
esr(config)# domain lookup enable
```

domain name

.

(no) .

```
domain name <NAME>
no domain name
```

<NAME>- , 1 31 .

10

CONFIG

:

```
esr(config)# domain name eltex-co.ru
```

domain name-server

IP- DNS-, DNS-
(no) DNS-.

[no] domain name-server <IP> [vrf <VRF>]

<IP>- IP- DNS-, AAA.BBB.CCC.DDD, [0..255];
<VRF>- VRF, 31 , DNS-.

10

CONFIG

:

```
esr(config)# domain name-server 172.16.0.1
```