

MES1024/1124/2124/3100

```
:  
console# delete startup-config  
console# reload  
  
:  
1. DHCP Discover .  
  
    MES1024/1124/2124/3100:  
43 - Vendor Specific  
66 - Server-Name  
67 - Bootfile-Name  
125 - V-I Vendor-Specific Information  
  
2. DHCP ACK      (, , , IP TFTP ).  
3. . .  
4. , .  
  
isc dhcp-server . :  
# 125  
option image-filename code 125 = {  
    unsigned integer 32,  
    unsigned integer 8,  
    unsigned integer 8,  
    unsigned integer 8,  
    text  
};  
  
shared-network "net" {  
  
    subnet 192.168.2.0 netmask 255.255.255.0 {  
        range 192.168.2.10 192.168.2.99;  
  
        filename "startup.cfg";  
        option image-filename 35265 20 1 18 "mes2000-114811.ros"; # 35265 - , 35265(Eltex)  
        # 20 - (mes2000-114811.ros) + 2  
        # 1 - , 1  
        # 18 - (mes2000-114811.ros)  
        # IP- TFTP  
        next-server 192.168.2.1;  
  
        option routers 192.168.2.1;  
        option subnet-mask 255.255.255.0;  
        option broadcast-address 192.168.2.254;  
    }  
}  
  
# 66-67option tftp-server code 66 = string;  
option bootfile-name code 67 = string;  
  
shared-network "net" {  
  
    subnet 192.168.2.0 netmask 255.255.255.0 {  
        range 192.168.2.10 192.168.2.99;  
  
        option tftp-server "192.168.2.1"; # IP- TFTP  
        option bootfile-name "startup.cfg"; #  
  
        option routers 192.168.2.1;  
        option subnet-mask 255.255.255.0;  
        option broadcast-address 192.168.2.254;  
    }  
}  
  
# 43  
option space vendor_43;  
option vendor_43.image-name_43 code 1 = string;  
option vendor_43.bootfile-name_43 code 2 = string;  
option vendor_43.configfile-name_43 code 3 = string;  
option vendor_43.tftp-server_43 code 4 = string;
```

```
shared-network "net" {
    subnet 192.168.2.0 netmask 255.255.255.0 {
        range 192.168.2.10 192.168.2.99;

        vendor-option-space vendor_43;
        option vendor_43.image-name_43 "mes2000-114811.ros"; #
        option vendor_43.bootfile-name_43 "franchise_boot-0017.rfb"; #
        option vendor_43.configfile-name_43 "startup.cfg"; #
        option vendor_43.tftp-server_43 "192.168.2.1"; # IP- TFTP

        option routers 192.168.2.1;
        option subnet-mask 255.255.255.0;
        option broadcast-address 192.168.2.254;
    }
}

:
: -> Config
,
.
Boot , boot boot DHCP .
,
startup-config.
```