

ACS NTU-RG-5420G-Wac NTU-RG-5440G-Wac

ACS , ONT. ACS ONT . .

, . :

```
VLAN :
set property InternetGatewayDevice.Layer2Bridging.Bridge.1.VLANID 1220 nocheck
set property InternetGatewayDevice.Layer2Bridging.Marking.4.VLANIDMark 1220 nocheck
```

```
VLAN :
set property InternetGatewayDevice.Layer2Bridging.Bridge.2.VLANID 399 nocheck
set property InternetGatewayDevice.Layer2Bridging.Marking.5.VLANIDMark 399 nocheck
```

vlan id " Vlan :", "vlan :". , , . .

ACS. ACS, "set property" "nocheck".
, ACS :

set property InternetGatewayDevice.Layer2Bridging.Marking.1.MarkingEnable TRUE nocheck

ACS:

InternetGatewayDevice.Layer2Bridging.Marking.1.MarkingEnable TRUE

, :

<https://eltex-co.ru/support/>
<https://servicedesk.eltex-co.ru/>

ONT LAN-. , "01-Ipoe_static", 0 1 LAN- Ipoe_static. "0-PPPoE_1-Bridge", 0 LAN- PPPoE, 1 LAN- bridge.

:

1. IPoE DHCP - [ntu-rg-5420gwac_0123-IPoE-dhcp.txt](#)
2. IPoE Static - [ntu-rg-5420gwac_0123-IPoE-Static.txt](#)
3. PPPoE - [ntu-rg-5420gwac_0123-PPPoE.txt](#)
4. IPoE DHCP (1, 2 LAN) + IPoE multicast proxy + Bridge STB (3, 4 LAN) - [ntu-rg-5420gwac_01-IPoE-dhcp_23-Bridge_Multicast.txt](#)
5. PPPoE (1, 2 LAN) + IPoE multicast proxy + Bridge STB (3, 4 LAN) - [ntu-rg-5420gwac_01-PPPoE_23-Bridge_Multicast.txt](#)
6. BRIDGE - [ntu-rg-5420gwac_0123-Bridge.txt](#)