

[LTP-] (debug)

OLT

```
LTP-X# configure terminal
```

:

```
LTP-X(config)# logging system loglevel debug
```

:

```
LTP-X(config)# logging file loglevel debug
```

syslog:

```
LTP-X(config)# logging remote 172.110.6.10 544 // syslog
```

, :

pmchal-gpon
pmchal-ipc
pmchal-machine
pmchal-olt
pmchal-ont
pmchal-gpon-port
pmchal-scheduler
pmchal-dhcpra
pmchal-dhcpv6ra
pmchal-pppoeia
pmchal-rdn
snmp
alarm
dhcpd

, ONT, OLT-, DHCP-relay .

```
LTP-X(config)# logging module pmchal-ont loglevel debug  
LTP-X(config)# logging module pmchal-olt loglevel debug  
LTP-X(config)# logging module pmchal-dhcpra loglevel debug
```

:

```
LTP-X(config)# do commit  
LTP-X(config)# do save
```

CLI:

```
LTP# show logging module all
Log:
Submodule [pmchal-gpon]:
Log level: notice
Submodule [pmchal-ipc]:
Log level: notice
Submodule [pmchal-machine]:
Log level: notice
Submodule [pmchal-olt]:
Log level: debug
Submodule [pmchal-ont]:
Log level: debug
Submodule [pmchal-gpon-port]:
Log level: notice
Submodule [pmchal-scheduler]:
Log level: notice
Submodule [pmchal-dhcpra]:
Log level: debug
Submodule [pmchal-pppoeia]:
Log level: notice
Submodule [pmchal-rdn]:
Log level: notice
Submodule [snmp]:
Log level: notice
Submodule [alarm]:
Log level: notice
Submodule [dhcpd]:
Log level: notice
Submodule [pmchal-dhcpv6ra]:
Log level: notice
```

```
LTP# show logging
Log:
Remote syslog: 172.110.6.10
Port: 544
Size: 16384
Save logs between boots: false
Log input commands: false
Destinations:
System: debug
Console: critical
Remote shells: critical
File: debug
```

, :

```
LTP-X# configure terminal
LTP-X(config)# logging system loglevel notice
LTP-X(config)# logging file loglevel notice
LTP-X(config)# logging module pmchal-ont loglevel notice
LTP-X(config)# logging module pmchal-olt loglevel notice
LTP-X(config)# logging module pmchal-dhcpra loglevel notice
LTP-X(config)# do commit
LTP-X(config)# do save
```