

ACS NTU-RG-5402G-W

ACS , ONT. ACS ONT . .
 , . :

```
VLAN :  
set property InternetGatewayDevice.Layer2Bridging.Bridge.1.VLANID 1220 nocheck  
set property InternetGatewayDevice.Layer2Bridging.Marking.4.VLANIDMark 1220 nocheck  
  
VLAN :  
set property InternetGatewayDevice.Layer2Bridging.Bridge.2.VLANID 399 nocheck  
set property InternetGatewayDevice.Layer2Bridging.Marking.5.VLANIDMark 399 nocheck
```

vlan id "Vlan :", "vlan :". , , . .

ACS. ACS, "set property" "nocheck".
, ACS :

set property InternetGatewayDevice.Layer2Bridging.Marking.1.MarkingEnable TRUE nocheck

ACS:

InternetGatewayDevice.Layer2Bridging.Marking.1.MarkingEnable TRUE

, :

<https://eltex-co.ru/support/>
<https://servicedesk.eltex-co.ru/>

ONT LAN-, "01-lpoe_static", 0 1 LAN- lpoe_static. "0-PPPoE_1-Bridge", 0 LAN- PPPoE, 1 LAN- bridge.

:

1. PPPoE + VoIP (FXS) IPoE Static + Bridge (LAN 4) - [ntu-rg-5402g-w_012-PPPoE_3-Bridge_fxs-VoIP-Static.txt](#)
2. Bridge (LAN 1,2,3,4) - [ntu-rg-5402g-w_012-Bridge.txt](#)
3. PPPoE + VoIP (FXS) IPoE DHCP - [ntu-rg-5402g-w_0123-PPPoE_fxs-VoIP-dhcp.txt](#)
4. Bridge (LAN 1,2,3,4) + Bridge (WiFi) + TR telnet http - [ntu-rg-5402g-w_0123-Bridge_Wifi-Bridge2.txt](#)