

ACS NTU-RG-5421G-Wac

ACS , ONT. ACS ONT . .

, . :

```
VLAN :
set property InternetGatewayDevice.Layer2Bridging.Bridge.1.VLANID 1220 nocheck
set property InternetGatewayDevice.Layer2Bridging.Marking.4.VLANIDMark 1220 nocheck
```

```
VLAN :
set property InternetGatewayDevice.Layer2Bridging.Bridge.2.VLANID 399 nocheck
set property InternetGatewayDevice.Layer2Bridging.Marking.5.VLANIDMark 399 nocheck
```

vlan id " Vlan :", "vlan :". , , . .

ACS. ACS, "set property" "nocheck".
, ACS :

set property InternetGatewayDevice.Layer2Bridging.Marking.1.MarkingEnable TRUE nocheck

ACS:

InternetGatewayDevice.Layer2Bridging.Marking.1.MarkingEnable TRUE

, :

<https://eltex-co.ru/support/>
<https://servicedesk.eltex-co.ru/>

ONT LAN-. , "01-lpoe_static", 0 1 LAN- lpoe_static. "0-PPPoE_1-Bridge", 0 LAN- PPPoE, 1 LAN- bridge.

:

1. IPoE DHCP - [ntu-rg-5421gwac_0123-IPoE-dhcp.txt](#)
2. IPoE DHCP (1, 2, 3 LAN) + Bridge (4 LAN) - [ntu-rg-5421gwac_012-IPoE-dhcp_3-Bridge.txt](#)
3. IPoE DHCP (1, 2, 3 LAN) + Bridge (4 LAN) + VoIP (FXS) IPoE DHCP - [ntu-rg-5421gwac_012-IPoE-dhcp_3-Bridge_Multicast_fxs-VoIP.txt](#)
4. PPPoE - [ntu-rg-5421gwac_0123-PPPoE.txt](#)
5. PPPoE (1, 2, 3 LAN) + IPoE multicast proxy + Bridge STB (4 LAN) + VoIP (FXS) IPoE DHCP - [ntu-rg-5421gwac_012-PPPoE_3-Bridge_Multicast_fxs-VoIP.txt](#)
6. PPPoE (1, 2, 3 LAN) + Bridge STB (4 LAN) + VoIP (FXS) IPoE DHCP - [ntu-rg-5421gwac_012-PPPoE_4-Bridge_fxs-VoIP.txt](#)
7. PPPoE + Multicast - [ntu-rg-5421gwac_0123-PPPoE_Multicast.txt](#)
8. PPPoE + Multicast + VoIP (FXS) IPoE DHCP - [ntu-rg-5421gwac_0123-PPPoE_Multicast_fxs-VoIP.txt](#)