

v1.22_ SMS (smsc.ru) HTTP/HTTPS

SWLC

:

/etc/eltex-ngw/application.conf :

```
/etc/eltex-ngw/application.conf
```

```
outgoing.config = "smsc.conf"
```

/etc/eltex-ngw/gateway.d/smsc.conf login, password **SMSC**, http/https Sender ID:

```
/etc/eltex-ngw/gateway.d/smsc.conf
```

```
connection {
    login = "test"          //
    password = "pass123"    //
    protocol = http         //
}

common {
    sender = smsc           // , . , , . - 11 15 .
    use_translit = false     // ,
                            //0 ( ) - .
                            //1 - "translit".
                            //2 - "mpaHc/Ium".
    charset = utf-8         //
}
```

NGW :

```
sudo service eltex-ngw restart
```

```
"SMS" "" - " "( , ).
```

