

v1.22_ SMS (smc.ru) HTTP/HTTPS

SWLC

:
/etc/eltex-ngw/application.conf :

```
/etc/eltex-ngw/application.conf

outgoing.config = "smc.conf"
```

/etc/eltex-ngw/gateway.d/smc.conf login, password **SMC**, http/https Sender ID:

```
/etc/eltex-ngw/gateway.d/smc.conf

connection {
    login = "test" //
    password = "pass123" //
    protocol = http //
}

common {
    sender = smc // , . , , . - 11 15 .
    use_translit = false // , .
    //0 ( ) - .
    //1 - "translit".
    //2 - "mpaHc/Ium".

    charset = utf-8 //
}
```

NGW :

```
sudo service eltex-ngw restart
```

"SMS" ""-"" (,).

