

QoS MES14xx, MES24xx, MES3400-xx, MES37

FIFO: – (First In – First Out). , , FIFO, . , . QoS (Quality of service –), .

```
console#sh qos trust
```

```
IfIndex Trust mode
```

```
-----
```

```
gi 0/1      none
```

```
gi 0/2      none
```

```
.....
```

```
.      qos trust {cos | dscp | cos-dscp| none}
```

```
console(config)#interface gigabitethernet 0/1
```

```
console(config-if)#qos trust cos
```

```
console(config)#interface gigabitethernet 0/2
```

```
console(config-if)#qos trust dscp
```

```
console#show qos trust
```

```
IfIndex Trust mode
```

```
-----
```

```
gi 0/1      CoS
```

```
gi 0/2      DSCP
```

```
.....
```

MES14xx, MES24xx, MES3400-xx, MES37 8 . qos - Strict priority (SP) Weighted Round Robin (WRR).