

3.20.3.

: web-, elnet, SSH RS-232 (RS-232, SSH Telnet CLI).



. «/ Flash» web- copy running to startup CLI.

- [3.20.3. SMG web-](#)
- [3.20.3. CLI \(SMG\)](#)