

DHCP relay MES23xx/33xx/35xx/5324

DHCP Relay . DHCP Relay DHCP- , DHCP- , . DHCP- (, 82).

DHCP Relay : DHCP- , (, ,). , .

. :

1) dhcp relay:

```
ip dhcp relay enable
```

2) ip- dhcp- (192.168.10.5):

```
ip dhcp relay address 192.168.10.5
```

3) dhcp option 82 ():

```
ip dhcp information option
```

dhcp option 82:

```
ip dhcp relay information option suboption-type custom
```

```
ip dhcp relay information option suboption-type tr101
```

4) dhcp relay vlan:

```
interface vlan 1
```

```
ip dhcp relay enable
```

```
ip address 192.168.1.1
```

5) vlan' dhcp- ip-:

```
interface vlan 10
```

```
ip address 192.168.10.1
```

DHCP- , (interface vlan 1)

. dhcp relay, :

1) dhcp relay:

```
ip dhcp relay enable
```

2) ip- dhcp- (192.168.10.5):

```
ip dhcp relay address 192.168.10.5
```

3) dhcp option 82 (). :

```
ip dhcp relay information option suboption-type custom
```

```
ip dhcp relay information option suboption-type tr101
```

4) dhcp relay vlan:

```
interface vlan 1
```

```
ip dhcp relay enable
```

5) vlan' dhcp- ip-:

```
interface vlan 10
```

```
ip address 192.168.10.1
```

DHCP- , 82, DHCP Relay.