

WEB / Telnet ONT

NTU-RG-14XX:

WEB- admin WAN PPP Connection , "" ACS.

Telnet TR-069 :

```
"InternetGatewayDevice.UserInterface.X_WebUserInfo.X_Security.AclServices.TelnetIpHostEnable" "1"
```

Telnet WAN :

```
"InternetGatewayDevice.UserInterface.X_WebUserInfo.X_Security.AclServices.TelnetWanEnable" "1"
```

Telnet LAN :

```
"InternetGatewayDevice.UserInterface.X_WebUserInfo.X_Security.AclServices.TelnetLanEnable" "1"
```

WEB TR-069 :

```
"InternetGatewayDevice.UserInterface.X_WebUserInfo.X_Security.AclServices.HTTPIpHostEnable" "1"
```

WEB WAN :

```
"InternetGatewayDevice.UserInterface.X_WebUserInfo.X_Security.AclServices.HTTPWanEnable" "1"
```

IP-:

:

```
"InternetGatewayDevice.UserInterface.X_WebUserInfo.X_Security.AclServices.WanAccessSourceIP" "0.0.0.0"  
"InternetGatewayDevice.UserInterface.X_WebUserInfo.X_Security.AclServices.WanAccessSourceMask" "0.0.0.0"
```

NTU-RG-54XX / NTU-52X:

WEB- admin WAN PPP Connection , "" ACS.

:

```
"InternetGatewayDevice.UserInterface.RemoteAccess.1.Enable" "1"  
"InternetGatewayDevice.UserInterface.RemoteAccess.1.Interface" "LAN"  
"InternetGatewayDevice.UserInterface.RemoteAccess.1.IP" "0.0.0.0"  
"InternetGatewayDevice.UserInterface.RemoteAccess.1.Mask" "0.0.0.0"  
"InternetGatewayDevice.UserInterface.RemoteAccess.1.Port" "80"  
"InternetGatewayDevice.UserInterface.RemoteAccess.1.Protocol" "HTTP"  
"InternetGatewayDevice.UserInterface.RemoteAccess.2.Enable" "1"  
"InternetGatewayDevice.UserInterface.RemoteAccess.2.Interface" "LAN"  
"InternetGatewayDevice.UserInterface.RemoteAccess.2.IP" "0.0.0.0"  
"InternetGatewayDevice.UserInterface.RemoteAccess.2.Mask" "0.0.0.0"  
"InternetGatewayDevice.UserInterface.RemoteAccess.2.Protocol" "ICMP"
```

icmp TR-069 :

```
"InternetGatewayDevice.UserInterface.RemoteAccess.3.Enable" "1"  
"InternetGatewayDevice.UserInterface.RemoteAccess.3.Interface" "nas0_0"  
"InternetGatewayDevice.UserInterface.RemoteAccess.3.IP" "0.0.0.0"  
"InternetGatewayDevice.UserInterface.RemoteAccess.3.Mask" "0.0.0.0"  
"InternetGatewayDevice.UserInterface.RemoteAccess.3.Protocol" "ICMP"
```

WEB TR-069 :

```
"InternetGatewayDevice.UserInterface.RemoteAccess.4.Enable" "1"
"InternetGatewayDevice.UserInterface.RemoteAccess.4.Interface" "nas0_0"
"InternetGatewayDevice.UserInterface.RemoteAccess.4.IP" "0.0.0.0"
"InternetGatewayDevice.UserInterface.RemoteAccess.4.Mask" "0.0.0.0"
"InternetGatewayDevice.UserInterface.RemoteAccess.4.Port" "80"
"InternetGatewayDevice.UserInterface.RemoteAccess.4.Protocol" "HTTP"
```

WAN, .

Telnet, "TELNET" 23 :

```
"InternetGatewayDevice.UserInterface.RemoteAccess.4.Port" "23"
"InternetGatewayDevice.UserInterface.RemoteAccess.4.Protocol" "TELNET"
```

NTU-52W:

NTU-RG-54XX .

WEB- admin WAN PPP Connection , "" ACS.
:

```
"InternetGatewayDevice.UserInterface.RemoteAccess.1.Enable" "1"
"InternetGatewayDevice.UserInterface.RemoteAccess.1.Interface" "LAN"
"InternetGatewayDevice.UserInterface.RemoteAccess.1.IP" "0.0.0.0"
"InternetGatewayDevice.UserInterface.RemoteAccess.1.Mask" "0.0.0.0"
"InternetGatewayDevice.UserInterface.RemoteAccess.1.Port" "80"
"InternetGatewayDevice.UserInterface.RemoteAccess.1.Protocol" "HTTP"
"InternetGatewayDevice.UserInterface.RemoteAccess.2.Enable" "1"
"InternetGatewayDevice.UserInterface.RemoteAccess.2.Interface" "LAN"
"InternetGatewayDevice.UserInterface.RemoteAccess.2.IP" "0.0.0.0"
"InternetGatewayDevice.UserInterface.RemoteAccess.2.Mask" "0.0.0.0"
"InternetGatewayDevice.UserInterface.RemoteAccess.2.Protocol" "ICMP"
"InternetGatewayDevice.UserInterface.RemoteAccess.3.Enable" "1"
"InternetGatewayDevice.UserInterface.RemoteAccess.3.Interface" "nas0_0"
"InternetGatewayDevice.UserInterface.RemoteAccess.3.IP" "0.0.0.0"
"InternetGatewayDevice.UserInterface.RemoteAccess.3.Mask" "0.0.0.0"
"InternetGatewayDevice.UserInterface.RemoteAccess.3.Protocol" "ICMP"
```

WEB TR-069 :

```
"InternetGatewayDevice.UserInterface.RemoteAccess.4.Enable" "1"
"InternetGatewayDevice.UserInterface.RemoteAccess.4.Interface" "InternetGatewayDevice.WANDevice.1.
WANConnectionDevice.1.WANIPConnection.1"
"InternetGatewayDevice.UserInterface.RemoteAccess.4.IP" "0.0.0.0"
"InternetGatewayDevice.UserInterface.RemoteAccess.4.Mask" "0.0.0.0"
"InternetGatewayDevice.UserInterface.RemoteAccess.4.Port" "80"
"InternetGatewayDevice.UserInterface.RemoteAccess.4.Protocol" "HTTP"
```

TELNET PPPoE :

```
"InternetGatewayDevice.UserInterface.RemoteAccess.5.Enable" "1"
"InternetGatewayDevice.UserInterface.RemoteAccess.5.Interface" "InternetGatewayDevice.WANDevice.1.
WANConnectionDevice.1.WANPPPConnection.1"
"InternetGatewayDevice.UserInterface.RemoteAccess.5.IP" "0.0.0.0"
"InternetGatewayDevice.UserInterface.RemoteAccess.5.Mask" "0.0.0.0"
"InternetGatewayDevice.UserInterface.RemoteAccess.5.Port" "23"
"InternetGatewayDevice.UserInterface.RemoteAccess.5.Protocol" "TELNET"
```