

(port forwarding) ONT

NTU-RG-54XX / NTU-52V

TCP 100 192.168.1.100. IPoE WAN.

```
set property "InternetGatewayDevice.WANDevice.1.WANConnectionDevice.1.WANIPConnection.2.PortMapping.1.ExternalPort" "100" nocheck
set property "InternetGatewayDevice.WANDevice.1.WANConnectionDevice.1.WANIPConnection.2.PortMapping.1.InternalClient" "192.168.1.100" nocheck
set property "InternetGatewayDevice.WANDevice.1.WANConnectionDevice.1.WANIPConnection.2.PortMapping.1.InternalPort" "100" nocheck
set property "InternetGatewayDevice.WANDevice.1.WANConnectionDevice.1.WANIPConnection.2.PortMapping.1.PortMappingDescription" "TEST" nocheck
set property "InternetGatewayDevice.WANDevice.1.WANConnectionDevice.1.WANIPConnection.2.PortMapping.1.PortMappingEnabled" "TRUE" nocheck
set property "InternetGatewayDevice.WANDevice.1.WANConnectionDevice.1.WANIPConnection.2.PortMapping.1.PortMappingProtocol" "TCP" nocheck
set property "InternetGatewayDevice.WANDevice.1.WANConnectionDevice.1.WANIPConnection.2.PortMapping.1.RemoteHost" "0.0.0.0" nocheck
set property "InternetGatewayDevice.WANDevice.1.WANConnectionDevice.1.WANIPConnection.2.PortMapping.1.X_ELTEX_RU_ExternalPortEnd" "100" nocheck
set property "InternetGatewayDevice.WANDevice.1.WANConnectionDevice.1.WANIPConnection.2.PortMapping.1.X_ELTEX_RU_InternalPortEnd" "100" nocheck
```

WAN-, , PPPoE, property **WANIPConnection.2. WANPPPPConnection.1.**

:

1. "PortMappingEnabled" "TRUE" - NAT
2. "ExternalPort" -
3. "ExternalPortEnd" -
4. "InternalPort" -
5. "InternalPortEnd" -
6. "PortMappingProtocol" - ("TCP or UDP", "TCP", "UDP")
7. "InternalClient" - ,
8. "PortMappingDescription" "TEST" - NAT