

QoS MES23xx/33xx/35xx/5324

QoS (Quality of service –), , 8 . Strict Priority.

FIFO: – (First In – First Out).

QoS.

qos trust cos / dscp / dscp-cos

- cos - 802.1p 802.1q
- dscp - DSCP IP-
- cos/dscp - IP-, DSCP, L2- (PPPoE), cos.

show qos

console# **sh qos**

Qos: Basic mode

Basic trust: cos-dscp

CoS to DSCP mapping: disabled

DSCP to CoS mapping: disabled

cos/dscp

DSCP :

console# **show qos map dscp-queue**

Dscp-queue map:

d1:	d2	0	1	2	3	4	5	6	7	8	9
0	:	02	01	01	01	01	01	01	01	01	03
1	:	03	03	03	03	03	03	07	04	04	04
2	:	04	04	04	04	07	05	05	05	05	05
3	:	05	05	07	06	06	06	06	06	06	06
4	:	07	08	08	08	08	08	08	08	07	07
5	:	07	07	07	07	07	07	07	07	07	07
6	:	07	07	07	07						

, -, DSCP 36 06

qos map dscp-queue <dscp-list> to <queue number>

cos :

show qos interface queuing

.....

Cos-queue map:

cos-qid

0 - 1

1 - 1

2 - 2

3 - 3

4 - 3

5 - 4

6 - 4

7 - 4

wrr-queue cos-map <queue number> <cos values>

/ [QoS MES23xx/33xx/35xx/5324](#)