

v1.14_Notification GW

-
- /
-
- /etc/eltex-ngw/notification.properties
- /etc/default/eltex-ngw
- SMS

SMS-, Call- , Wi-Fi .

eltex-ngw.

/

:

```
service eltex-ngw stop
```

:

```
service eltex-ngw start
```

— , :

```
service eltex-ngw status
```

, , :

```
eltex-ngw start/running, process <pid>
```

, :

```
eltex-ngw stop/waiting
```

/etc/eltex-ngw/notification.properties

, :

- SMS (SMS)

```
sms.gate.outgoing.sms.config=smc_gate.conf
```

- SMS:

```
sms.gate.incoming.sms.config=smpp_gate.conf
```

- :

```
sms.gate.incoming.call.config=rtk_sbc.conf
```

- SMS :

```
#Gate pool settings
sms.gate.pool.size=50
sms.gate.pool.wait.millis=5000
```

-

```
#Call gate configuration
call.gate.outgoing.call.config=smg_gate.conf
call.gate.pool.size=50
pool.wait.millis=5000
```

- , :

```
#Port to listen for requests
server.port=8040
```

- MongoDB

```
=====
#####database settings#####
=====
#mongodb.uri=mongodb://192.168.1.1,192.168.1.2:27017/notification-gw
mongodb.host=localhost
mongodb.port=27017
#mongodb.user=user
#mongodb.password=password
mongodb.name=notification-gw
mongodb.fsfiles.store.period=7
```



replicaSet mongo.uri. :

```
mongodb://[username:password@]host1[:port1][,host2[:port2],...[,hostN[:portN]]][/[database][?options]]
```

replicaSet

```
mongodb.uri=mongodb://admin_ngw:password@192.168.42.224:27017,192.168.42.225:27017,192.168.42.226:27017/notification-gw?replicaSet=clustest
```

-

```
=====
#####email settings#####
=====
mail.smtp.submitter=example@eltex.loc
mail.smtp.password=password
mail.smtp.auth=true
mail.smtp.host=eltex.loc
mail.smtp.port=587
mail.smtp.sendpartial=true
mail.smtp.connectiontimeout=5000
mail.gate.pool.size=20
mail.pool.wait.millis=10000
```



:

```
mail.smtp.starttls.enable=true
```

/etc/default/eltex-ngw

```
JAVA_INIT_HEAP=16m
# Maximum size of Java heap
JAVA_MAX_HEAP=128m

LOG_LEVEL=info

# Additional arguments to pass to java
JAVA_OPTS="-XX:+HeapDumpOnOutOfMemoryError -XX:HeapDumpPath=/var/log/eltex-ngw"
```

JAVA_INIT_HEAP - ,

JAVA_MAX_HEAP - ,

LOG_LEVEL - : error, warning, info, debug

JAVA_OPTS - java

SMS

SMS . , .

- SMS - smsc_gate.conf
- Seven Sky - 7sky_gate.conf
- - zagruzka_gate.conf
- SMS - SMPP - smpp_gate.conf
- GSM- NetPing SMS - netping_gate.conf
- GSM- Fargo maestro 100 - serial_port.conf
- - levob_gate.conf ()
- - sviaz_bank_gate.conf ()
- - rtk_sbc.conf, rtk_gate.conf ()

.