

# ESR

- ESR
- ESR
- ESR

## ESR

ESR :

- BRAS - // . RADIUS-. IP MAC- .
- BRAS-DEMO - BRAS- 5 .
- WIFI - SoftGRE- WiFi- .
- WISLA - IP SLA wisla.
- IPS - IDS/IPS.
- IPS-DEMO - IDS/IPS (IDS/IPS ).
- AS DEMO - Antispam.
- WLC - Wi-Fi .
- WLC-AP-N - Wi-Fi .

## ESR

ESR :

|            | BRAS-DEMO | BRAS | WI-FI | WISLA | IPS-DEMO | IPS | AS DEMO | WLC | WLC-AP-N |
|------------|-----------|------|-------|-------|----------|-----|---------|-----|----------|
| ESR-10     | +         | +    | -     | +     | +        | +   | +       | -   | -        |
| ESR-12V(F) | +         | +    | -     | +     | +        | +   | +       | -   | -        |
| ESR-15(R)  | +         | +    | +     | +     | +        | +   | +       | +   | +        |
| ESR-20     | +         | +    | -     | +     | +        | +   | +       | -   | -        |
| ESR-21     | +         | +    | -     | +     | +        | +   | +       | -   | -        |
| ESR-30     | +         | +    | +     | +     | +        | +   | +       | -   | -        |
| ESR-100    | +         | +    | +     | +     | +        | +   | +       | -   | -        |
| ESR-200    | +         | +    | +     | +     | +        | +   | +       | -   | -        |
| ESR-1000   | +         | +    | +     | +     | +        | +   | +       | -   | -        |
| ESR-1200   | +         | +    | +     | +     | +        | +   | +       | -   | -        |
| ESR-1500   | +         | +    | +     | +     | +        | +   | +       | -   | -        |
| ESR-1511   | +         | +    | -     | +     | +        | +   | +       | -   | -        |
| ESR-1700   | +         | +    | +     | +     | +        | +   | +       | -   | -        |
| ESR-3100   | +         | +    | -     | -     | +        | +   | +       | -   | -        |
| ESR-3200   | +         | +    | +     | +     | +        | +   | +       | +   | +        |

## ESR

ESR ESR system:license copy. FTP,TFTP,SFTP,SCP,HTTP, USB MMC :

```
esr# copy tftp://192.168.34.2:/licence system:licence
|*****| 100% (672B) Licence loaded successfully. Please reboot system to
apply changes.
esr-1200#
```

show licence:

```
esr# show licence
Active licence not found!
```

After reboot:

```
-----
Name:    Eltex
Version: 1.0
Type:    ESR-1200
S/N:     NP0C000022
MAC:     A8:F9:4B:AB:D7:00
Features:
  IPS - Intrusion Prevention System
esr#
esr#
```

. :

```
esr# show licence
Licence information
-----
Name:    Eltex
Version: 1.0
Type:    ESR-1200
S/N:     NP0C000022
MAC:     A8:F9:4B:AB:D7:00
Features:
  IPS - Intrusion Prevention System
esr#
esr#
```



ESR !, , , :

```
esr# show licence
Licence information
-----
Name:    Eltex
Version: 1.0
Type:    ESR-1200
S/N:     NP0C000022
MAC:     A8:F9:4B:AB:D7:00
Features:
  WIFI - Wi-Fi controller

After reboot:
-----
Name:    Eltex
Version: 1.0
Type:    ESR-1200
S/N:     NP0C000022
MAC:     A8:F9:4B:AB:D7:00
Features:
  IPS - Intrusion Prevention System
esr-1200#
```

WIFI , Wi-Fi, .

, "Eltex" , .