

errdisable MES23xx/33xx/35xx/5324

```
mes errdisable. , - . , :  
console# show errdisable recovery  
Timer interval: 30 Seconds  
  


| Reason             | Automatic Recovery |
|--------------------|--------------------|
| loopback_detection | Disable            |
| port-security      | Disable            |
| dot1x-src-address  | Disable            |
| acl-deny           | Disable            |
| stp-bpdu-guard     | Disable            |
| stp-loopback-guard | Disable            |
| udld               | Disable            |
| storm-control      | Disable            |
| link-flapping      | Enable             |
| l2pt-guard         | Disable            |
| pvst               | Disable            |

  
, - errdisable . .  
gig0/2 spanning-tree bpduguard. , bpdu, errdisable:  
  
console(config-if)# do sh run int gig0/2  
interface gigabitethernet1/0/2  
spanning-tree bpduguard enable  
switchport mode trunk  
switchport trunk allowed vlan add 100,111-112  
!  
  
:  
  
console(config-if)#09-Nov-2018 14:39:38 %STP-W-BPDUGRDPTSUS: g1/0/2 suspend by BPDU guard.  
09-Nov-2018 14:39:38 %LINK-W-PORT_SUSPENDED: Port g1/0/2 suspended by stp-bpdu-guard  
  
errdisable :  
console# show errdisable interfaces  
  


| Interface | Reason         |
|-----------|----------------|
| g1/0/2    | stp-bpdu-guard |

  
. . :  
console# set interface active gig0/2  
  
:  
  
console(config)# errdisable recovery cause stp-bpdu-guard  
  
300 () . , 30:  
console(config)# errdisable recovery interval  
<30-86400> Specify the timeout interval.
```