

MES1024/1124/2124/3100

— , . MES , , .

:

- Ethernet (, tengigabitethernet 1/0/1):

```
console(config)# interface tengigabitethernet 1/0/1
```

```
console(config-if)# storm-control broadcast enable
```

- (, 8500 /):

```
console(config-if)# storm-control broadcast level kbps 8500
```

- : /

```
console(config-if)# storm-control broadcast logging
```

```
console(config-if)# storm-control broadcast shutdown
```