

Management ACL MES23xx/33xx/35xx/5324

Management ACL.

IP- (IP 192.168.1.12).

1. Management ACL IP- :

```
console# configure
console(config)# management access-list IP
console(config-macl)# permit ip-source 192.168.1.12
console(config-macl)# exit
```

2. Management ACL:

```
console(config)# management access-class IP
```

show:

```
console# show management access-list
IP
-----
permit ip-source 192.168.1.12
! (Note: all other access implicitly denied)

console-only
-----
deny
! (Note: all other access implicitly denied)

console#show management access-class
Management access-class is enabled, using access-list IP
```