

DHCP (bootpc) MES23xx/33xx/35xx/5324

DHCP ACL.

ACL. 1-27 . 28 uplink

1) IP ACL bootpc (port 68). ACL . ACL

```
ip access-list extended dhcp
deny udp any any any bootpc
permit ip any any any any
exit
```

2) ACL

```
interface range GigabitEthernet0/1-27
service-acl input dhcp
```