

Flex-Link MES23xx/33xx/35xx/5324

Flex-link – , . flex-link ethernet port-channel .

()

```
console(config)# interface gi0/1
```

```
console(config-if)# flex-link backup gi0/2
```

Gi0/1 - Active

Gi0/2 - Backup

preemption mode:

```
console(config-if)# flex-link preemption mode [ forced | band-width | off ]
```

- **forced** – master, ;

- **bandwidth** – ;

- **off** – .

:

1) MAC- backup-

2) preemption Flex Link ARP active-

3) IGMP Snooping Flex Link mrouter

4) preemption IGMP report