

!!![MA4000-PX] selective-qinq 4000?

Selective Q-in-Q S-VLAN C-VLAN, vlan.

, PLC-8 (slot 1) slot-channel 1 VLAN 32, vlan 596.

1. selective-qinq:

- MA4000(pp4x)#
- MA4000(pp4x)# configure
- MA4000(pp4x-config)# selective-qinq list 1

2. VLAN 32 VLAN 596:

- MA4000(pp4x-config-sel-qinq-1)# add-tag svlan 596 cvlan 32

3. q-in-q slot-channel 1:

- MA4000(pp4x-config)# interface slot-channel 1
- MA4000(pp4x-config-slot-channel-1)# selective-qinq enable
- MA4000(pp4x-config-slot-channel-1)# selective-qinq list 1
- MA4000(pp4x-config-slot-channel-1)# exit

4. VLAN PLC-8:

- MA4000(pp4x-config)# vlan 596
- MA4000(pp4x-config-vlan-596)# untagged slot-channel 1

5. :

- MA4000(pp4x-config-vlan-596)# do commit
- MA4000(pp4x-config-vlan-596)# do confirm

:

, VLAN 32 slot-channel 1, VLAN 596, , VLAN 596, slot-channel 1 .