

Flex-Link MES23xx/33xx/35xx/5324

Flex-link – , . flex-link ethernet port-channel .

()

console(config)# **interface gi0/1**

console(config-if)# **flex-link backup gi0/2**

Gi0/1 - Active

Gi0/2 - Backup

preemption mode:

console(config-if)# **flex-link preemption mode [forced | band-width | off]**

- **forced** – master, ;

- **bandwidth** – ;

- **off** – .

:

1) MAC- backup-

2) preemption Flex Link ARP active-

3) IGMP Snooping Flex Link mrouter

4) preemption IGMP report