

SNMP trap

, SoftWLC SNMP "Trap", :

1. WEB- .

"Services/SNMP" "Trap Destinations" "Enabled", "Host Type" - IPv4, "SNMP version" - snmpV2, "Community name" - public IP EMS, .

Trap Destinations

Enabled	Host Type	SNMP version	Community Name (Range: 1 - 256 characters)	Hostname or IP or IPv6 Address (xxx.xxx.xxx.xxx/xxxx:xxxx:xxxx:xxxx:xxxx:xxxx:xxxx:xxxx/Hostname max 255 Characters)
☒	IPv4 ▾	snmpV2 ▾	public	192.168.0.15
☐	IPv4 ▾	snmpV2 ▾		
☐	IPv4 ▾	snmpV2 ▾		

2. CLI :

- add traphost
- set traphost host-type ipv4
- set traphost trap_version snmpV2
- set traphost community public
- set traphost host <IP address EMS>
- save-running