

- [clock timezone](#)
- [key](#)
- [maxpoll](#)
- [minpoll](#)
- [ntp access-addresses](#)
- [ntp authentication enable](#)
- [ntp authentication key-chain](#)
- [ntp authentication trusted-key](#)
- [ntp broadcast-client enable](#)
- [ntp dscp](#)
- [ntp enable](#)
- [ntp ipv6 source address](#)
- [ntp object-group query-only](#)
- [ntp object-group serve-only](#)
- [ntp peer](#)
- [ntp server](#)
- [ntp source address](#)
- [prefer](#)
- [set date](#)
- [show date](#)
- [show ntp configuration](#)
- [show ntp peers](#)
- [version](#)

clock timezone

```
.
(no) .
```

```
clock timezone <OFFSET>
no clock timezone
```

<OFFSET> – , Greenwich Mean Time, [gmt -12 .. gmt +12].

```
gmt 0
```

```
15
```

```
CONFIG
```

```
:
```

```
esr(config)# clock timezone gmt +7
```

key

```
.
(no) .
```

```
key <ID>
no key
```

<ID> – , [1..255].

15

CONFIG-NTP

:

```
esr(config-ntp)# key 245
```

maxpoll

NTP-.

(no) .

maxpoll <INTERVAL>

no maxpoll

<INTERVAL> – . , , , [10..17].

10 ($2^{10} = 1024$ 17 4)

10

CONFIG-NTP

:

```
esr(ntp-remote)# maxpoll 11
```

minpoll

NTP-.

(no) .

minpoll <INTERVAL>

no minpoll

<INTERVAL> – , , , [4..6].

6 ($2^6 = 64$ 1 4)

10

CONFIG-NTP

:

```
esr(ntp-remote)# minpoll 4
```

ntp access-addresses

IP-, ntp-.

(no) .

ntp access-addresses <NAME>

no ntp access-addresses

<NAME> – IP-, 31 .

.

15

CONFIG

:

```
esr(config)# ntp access-addresses 192.168.16.33
```

ntp authentication enable

NTP-.

(no) .

[no] ntp authentication enable

.

.

15

CONFIG

:

```
esr(config)# ntp authentication enable
```

ntp authentication key-chain

md5 ,.

(no) .

ntp authentication key-chain <KEYCHAIN>

no ntp authentication key-chain

<KEYCHAIN> – , 16 .

15

CONFIG

:

```
esr(config)# ntp authentication key-chain lock
```

ntp authentication trusted-key

.

(no) .

[no] ntp authentication trusted-key <ID>

<ID> – , [1..255].

15

CONFIG

:

```
esr(config)# ntp authentication trusted-key 25
```

ntp broadcast-client enable

NTP- VRF. NTP-. NTP- , .

(no) .

[no] ntp broadcast-client enable

.

.

10

CONFIG

:

```
esr(config)# ntp broadcast-client enable
```

ntp dscp

DSCP IP- NTP-.

(no) DSCP .

ntp dscp <DSCP>

no ntp dscp

<DSCP> – DSCP, [0..63].

46

10

CONFIG

:

```
esr(config)# ntp dscp 40
```

ntp enable

NTP VRF.

(no) NTP.

[no] ntp enable

10

CONFIG

:

```
esr(config)# ntp enable
```

ntp ipv6 source address

source-IPv6- NTP- peer.

(no) source-IPv6- NTP- .

ntp ipv6 source address <IPv6-ADDR>

no ntp ipv6 source address

<IPv6-ADDR> – IPv6- RADIUS-, X:X:X:X::X, [0..FFFF].

IPv6-, NTP-.

10

CONFIG

:

```
esr(config)# ntp ipv6 source address fc00::1
```

ntp object-group query-only

query-only, NTP IP-. control messages.

(no) .

ntp object-group query-only <NAME>

no ntp object-group query-only

<NAME> – IP-, 31 .

NTP- .

15

CONFIG

:

```
esr(config)# ntp object-group query-only OG-NTP-Q0
```

ntp object-group serve-only

serve-only, NTP IP-. NTP-; control messages .

(no) .

ntp object-group serve-only <NAME>

no ntp object-group serve-only

<NAME> – IP-, 31 .

NTP-

15

CONFIG

:

```
esr(config)# ntp object-group serve-only OG-NTP-S0
```

ntp peer

NTP- CONFIG-NTP.

NTP- NTP-, . NTP-, -.

(no) NTP-.

[no] ntp peer { <ADDR> | <IPV6-ADDR> } [vrf <VRF>]

<ADDR> – IP-, AAA.BBB.CCC.DDD, [0..255];

<IPV6-ADDR> – IPv6-, X:X:X:X::X, [0..FFFF];

<VRF> – VRF, 31, NTP-.

10

CONFIG

:

```
esr(config)# ntp peer 10.100.100.1
esr(ntp-remote)#
```

ntp server

NTP- CONFIG-NTP.

NTP- . NTP.

(no) NTP-.

[no] ntp server { <ADDR> | <IPV6-ADDR> } [vrf <VRF>]

<ADDR> – IP-, AAA.BBB.CCC.DDD, [0..255];

<IPV6-ADDR> – IPv6-, X:X:X:X::X, [0..FFFF];

<VRF> – VRF, 31, NTP-.

10

CONFIG

:

```
esr(config)# ntp server 10.100.100.2
esr(ntp-remote)#
```

ntp source address

source-IP- NTP- peer.

(no) source-IP- NTP- .

ntp source address <ADDR>

no ntp source address

<ADDR> – IP-, AAA.BBB.CCC.DDD, [0..255].

IP-, NTP-.

10

CONFIG

:

```
esr(config)# ntp source address 10.100.100.2
```

prefer

NTP- . NTP- NTP-.

(no) .

[no] prefer

.

.

15

CONFIG-NTP

:

```
esr(ntp-remote)# prefer
```

set date

.

set date <TIME> [<DAY> <MONTH> [<YEAR>]]

<TIME> – , HH:MM:SS,:

- HH – , [0..23];
- MM – , [0 .. 59];
- SS – , [0 .. 59].

<DAY> – , [1..31];

<MONTH> – , [January/February/March/April/May/June/July/August/ September/October/November/December];

<YEAR> – , [2001..2037].

10

ROOT

:

```
esr# set date 16:35:00 15 May 2014
```

show date

.

show date

.

1

ROOT

:

```
esr# show date
Thursday 23:48:33 GMT+7 May 15 2014
```

show ntp configuration

(RUNNING) NTP.

show ntp configuration

.

10

ROOT

:

```
esr# show ntp configuration
NTP status: Enabled
NTP mode:   client/server
Address      Type    Prefer  NTP version  Min poll    Max poll
-----
10.100.100.1 peer    yes     NTPv4        6(1m 4s)    11(34m 8s)
10.100.100.2 peer    yes     NTPv4        6(1m 4s)    10(17m 4s)
1.2.3.4      server  no      NTPv4        6(1m 4s)    10(17m 4s)
```

show ntp peers

NTP- ().

6- ()

remote	DNS- IP- (). , 7.
refid	IP- , (). 8.
st	.
t	(), 9.
when	, () , ("h" ,"d").
poll	().
reach	, (1 = , 0 =), .
delay	() , .
offset	().
jitter	().

7 – ()

	, : • 0; • , ; • 0 .
x	() , .
-	() , .
#	() , , () , , .
+	() , .
*	() , .

8 – ()

.ACST.	Manycast-.
.AUTH.	.
.AUTO.	.
.BCST.	Broadcast-.
.CRYPT.	.
.DENY.	.
.INIT.	.
.MCST.	Multicast-.
.TIME.	.
.STEP.	, (1000) , , (125).
.RATE.	.

9 – ()

u	Unicast manycast-.
b	Broadcast unicast-.

s	().
A	Manycast-.
B	Broadcast-.
M	Multicast-.

show ntp peers

.

1

ROOT

:

```
esr# sh ntp peers
Clock is synchronized, stratum 3, reference is 192.168.1.1
  remote      refid      st t when poll reach  delay  offset  jitter
-----
*192.168.1.1  192.168.1.2    2 u  45  128  377   0.283   0.204   0.049
```

version

NTP-.

(no) .

version <VERSION>

no version

<VERSION> – NTP-, [1..4].

4

15

CONFIG-NTP

:

```
esr(ntp-remote)# version 3
```